

# Monteringsanvisning


Installation manual

- Port / Gate

# Monteringsanvisning

Installation manual


Accessories for gate:



Tools needed:





1.





# Monteringsanvisning

Installation manual



# Monteringsanvisning

Installation manual






# Monteringsanvisning

Installation manual

**FD-1 90:**

**FD-2 90:**

**FD-12 90:**



# Monteringsanvisning

Installation manual

**FD-1 100:**




**FD-2 100:**

**FD-12 100:**

**FD-1 120:**

**FD-2 120:**

**FD-12 120:**



# Monteringsanvisning

Installation manual


**FB-3:**

**FC-4:**

**FC-4D:**

**FB-5:**


**FC-5:**



# Monteringsanvisning

Installation manual

## FA-1:






# Monteringsanvisning

Installation manual

**FA-2:      FA-3:      FA-4:      FA-8:**  
**FA-12:    FE-2:      FE-12:**





# Monteringsanvisning




Installation manual

## 2.

### Ver. A:




### Ver. B:





# Monteringsanvisning

Installation manual



# Monteringsanvisning

Installation manual






# Monteringsanvisning

Installation manual



**/ x 2**






# Monteringsanvisning

Installation manual


3.

 = 5mm




# Monteringsanvisning

Installation manual



# Monteringsanvisning

Installation manual




/ x 2



# Monteringsanvisning

Installation manual


4.





# Monteringsanvisning

Installation manual





# Monteringsanvisning


Installation manual



# Monteringsanvisning

Installation manual



5.



# Monteringsanvisning

Installation manual

6.



# Monteringsanvisning

Installation manual

7.



= 4mm

