




VOYAGE DE LUXE IL15

Read the instructions carefully before using, and take care of it.



Product Parameters

Product No: IL15 Net Weight: ≈188g

Product Size: φ91*30mm Product Material: PC+Alloy Operating Voltage: DC 5V

Using Power: 2W

Executive Standard: GB/T 26572-2011

QC: Qualified



Product List

Aromatherapy Instrument 1pc, Essential Oil 1pc, Charging Cable 1pc, Anti-skid Pad 1pc, User Manual 1pc

Operating Instructions

Smart Mode: long press for 3 seconds to turn on.

Aroma Mode: press the switch once.

Fragrance Mode: press the switch again. Cycle in turn, press and hold the switch for 3 seconds to turn off.

Smart Mode

When switching to this mode, bright white light and spray once, then spray again after 20 seconds, then spray once every 1 minute, The duration of each fragrance spraying in the first hour is 0.3 seconds, and the duration of each fragrance spraying is 0.5 seconds after one hour. No vibration is detected for 5 minutes and it enters sleep mode.

Aroma Mode

Switch to this mode and spray twice, then spray twice after 20 seconds, then spray twice at 1 minute intervals, Each fragrance lasts for 0.2 seconds, and it enters sleep mode without detecting vibration for 5 minutes.

Fragrance Mode

Switch to this mode and spray once, spray again after 20 seconds, and spray once every 1 minute. Each fragrance lasts for 0.2 seconds, and it enters sleep mode without detecting vibration for 5 minutes.

Sleep Mode

It enters sleep mode without checking vibration for 5 minutes, reducing power consumption. Wake up when vibration is checked again.

Power Display

- 1 When the orange breathing light is displayed, it means that the battery is low and needs to be charged.
- ② It displays orange breathing light when charging.
- 3 The green light is always on when it is fully charged.

Note: The product supports charging while working, and it takes about 2 hours to charge.

Instructions




1. Unscrew cover and mount.



2. Take out essentrial oil bottle, unscrew bottle cap, pour into oil and cover.



3. Put well bottle and screw cover and mount.



4. Tear film and stick on appropriate place.



5. Press 3 seconds to open, select mode.



Built-in 250mAh polymer battery, charge through Type-C connector.

Cautions

- 1. Please use the essential oils provided by our company, and do not pour other essential oil liquids.
- Please do not overturn this product. If accidentally leaked, spray on fur, gold, pearl and other clothing products, please wipe it off immediately with a wet towel.
- 3.Do not strike or hit the product to avoid internal damage.
- 4.Do not make any unauthorized disassembly or modificatio to the product.
- 5.Do not charge the product with a voltage exceeding the specified value.
- 6.Do not throw the product into fire to avoid explosio.
- 7.Do not touch the product with wet hands.
- 8. Keep the product in a cool, dry place and away from children.

Made in china

Read the instructions carefully before using, and take care of it.

MANUFACTURED FOR: LÈLIOR GROUP LLC 1226 NW 23RD AVE FORT LAUDERDALE, FL 33311 INFO@LELIOR.COM

Maintenance

In order to ensure the best diffusing effect, please check and maintain the device every six month, or when you replace a new fragrance, or when the diffusing effect get weak as the following steps.

- 1. Take off the oil canister which is spent.
- 2. Filling industrial alcohol into the canister and clean it.
- 3. After clean the oil canister, refill canister with little alcohol and install it on the device then make the device stay in working status for 5-8 minutes.
- 4. Turn off the power when finishing cleaning.

Malfunction Debugging

Please try to solve the problem as below before fixing the machine.

Breakdown	Solution	Breakdown	Solution
Not working	-Check if power adapter is DC5V-1A, and check if DC power interface is well-connected or not. -Check if device is not in work period.	Oil leakage	-Check if canister connects to atomizer closelyCheck if seal ring is deformed or damaged -Check if atomizer is damaged.
No mist Mist gets weak	-Check if pump works or not, and if airflow from air outletCheck if atomizer core and oil tube are loose or blockedCheck if seal ring gets damaged or fall off.	Abnormal noise	-Check if air pump is loose, please fix it correctly. -Check if air pump is damage, please replace a new one.

After-sale Service

The warranty is 1 year from the date of sale, not including device shell, adapter, electric wires, seal ring and the other vulnerable parts, as well as the damage caused by human or accident. Permanent maintaining for value will be provided if the machine exceed the warranty.

If there is any issue of after-sales, please contact authorized sales service in corresponding area, or contact Sales Center directly.

Warranty Card

This card is the warranty for device's quality, please fill it with actual information.

Warranty card one	Warranty card two
Start Date of	Start Date of
Warranty Period	Warranty Period
Malfunction Description	Malfunction Description
Date of Verify	Date of Verify
Maintenance	Maintenance
Result	Result
Maintainer's	Maintainer's
Signature	Signature



MANUFACTURED BY: LÈLIOR GROUP LLC 1226 NW 23RD AVE FORT LAUDERDALE, FL 33311 INFO@LELIOR.COM



FOR MORE INFORMATION