


LE PETIT VOYAGE IL20

USER MANUAL

INTRODUCTION





KEY FEATURES & OPERATION

The IL20 boasts an all-aluminum construction, features a 1.5L/minute air pump, and includes a 10ml essential oil container. It emits an atomization volume of approximately 0.2g per hour, operates at a maximum power of IW, and covers a diffusion area of 100 square feet.

To power on the diffuser press the power/intensity button. To power off the diffuser, press and hold the power/intensity button for 5 seconds.

Intensity Settings:

To set the intensity level, press the power/intensity button.

- 1 Intensity Level 1: On for 5 seconds and paused for 300 seconds.
- 2 Intensity Level 2: On for 10 seconds and paused for 200 seconds.
- 3 Intensity Level 3: On for 15 seconds and paused for 100 seconds.


Timer Settings:

- 1) Press the timer button to set the amount of hours the diffuser will run.
- 2 Press and hold the timer button to set the diffuser to Start/Stop Mode. Start/Stop Mode allows the diffuser to run continuously. The three timing indicator lights will be illuminated when in Start/Stop Mode.

Device Status:

- ① Charging Status: The intensity lights will cycle through each light while charging.
- 2) Fully Charged Status: All 3 intensity lights will be illuminated when fully charged.
- 3 Low Battery Status: All 3 intensity lights will flash and the diffuser will turn off automatically after 5 seconds. Intensity

Control Panel Operating Instructions




Device status display

When charging: gear light cycle effect

When fully charged: the gear light is always on.

When the battery voltage is lower than 3.2V: Three gear indicator lights flash together, and automatically turn off after five seconds.

03 INSTRUCTIONS



Using Essential Oils:

Before adding essential oils, ensure the atomizing nozzle is removed.

Pour the oil into the chamber, then reattach the atomizing nozzle.

Avoid overfilling. Wait for a day before the next refill to ensure efficient diffusion.

MAINTENANCE

To achieve optimal scent diffusion, we recommend inspecting and maintaining the equipment every six months. Should you wish to switch to a new fragrance or notice a reduced scent intensity, it's crucial to assess and service the equipment.



Remove the atomizing head and essential oil bottle.



Pour a suitable amount of alcohol into the chamber.



Reattach the essential oil bottle atomizing head to the device. Turn on the device and let it work for 5-8 minutes



Once cleaning is complete, shutdown the device, remove and dry any excess alcohol from the essential oil bottle.

SILVER



BLACK



PARAMETERS

Product name	Le Petit Voyage	Product type	Car Aroma Diffuser
Product model	IL20	Product size	Ф66*145mm
Maximum power	1W	Product NrWeight	0.38kg
Input power	DC5V-1.5A (Type-C)	Overall weight	0.75kg
Coverage	250ft²	Packing List	Diffuser + Power Cord
battery capacity	2000MAH	Machine noise	≤30dB
Essential oil capacity	10mL	Atomization volume per hour	0.2g

06 TROUBLESHOOTING


Refer to the following solutions for common issues:

Fault Type	Possible Solutions	
Device not Working	Ensure it's charged and that the power button is pressed correctly.	
No Atomization	Check the amount of essential oil and ensure the nozzle is correctly placed.	
Oil Spill	Avoid overfilling the oil chamber.	
Abnormal Noise	Make sure the device is placed on a stable surface.	

WARNING

- Do not use damaged power cables or adapters to prevent damage or injury.
- If unfamiliar with the device's functioning, avoid disassembling or repairing it.
- Ensure the device operates in its designated mode.
- Do not immerse the device in water.
- If the device requires cleaning, ensure it's turned off before cleaning.
- For optimal performance, clean the device regularly.
- Avoid dismantling the device, as it may affect its functionality.

LE PETIT VOYAGE



MANUFACTURED FOR:
LÈLIOR GROUP LLC
1226 NW 23RD AVE
FORT LAUDERDALE, FL 33311
INFO@LELIOR.COM



