



LA TOUR IL700

USER MANUAL


01 INTRODUCTION





02 FUNCTION DESCRIPTION


- Press the button () to turn on the diffuser.
- Press the button M to switch between low, medium, and high gears.
- Low: working 15s, stop 200s
 Mid: working 15s, stop 100s
 High: working 15s, stop 60s



Device status display
When charging: gear light cycle effect
When fully charged: the gear light is always on.
When the battery voltage is lower than 3.2V: Three gear indicator lights flash together, and automatically turn off after five seconds.

03 Usage method

How to fill the oil bottle



- the atomizer.
- 1.Rotate and remove 2. Rotate and remove the oil bottle.
- 3. Fill the aromaoil to the diffuser bottle.
- 4. Attach the bottle and atomizer and it is ready to use.

How to change the oil

 \triangle 1.Stop the diffuser for 2 minutes before adding aroma oil, and remove the oil bottle after the oil flows back from the atomizer head.

riangle 2.lt is recommended to control the amount of aroma oil added each time within 45 days to avoid oxidation and deterioration of the aroma oil.

04 Maintenance

To ensure the best fragrance diffusion effect, customers should inspect and maintain the device every six months. When a new fragrance is needed or the diffusion effect is weak, the device should also be maintained:



1. Unscrew the used oil bottle.



Pour a suitable amount of alcohol into the oil bottle and clean the bottle.



After cleaning, pour a small amount of alcohol into the oil bottle and install it in the diffuser, and turn on the diffuser working for 5-8 minutes.



After the diffuser is cleaned, turn off the power.

05 Parameters

Product name	La Tour	Product type	Waterless aroma diffuser
Product model	IL700	Product size	200*Ф1012 mm
Power	2W	Net Weight	2.9kg
Input	DC5V-2A (Type-C)	Gross Weight	5kg
Coverage	3500ft ²	Packing list	Aroma diffuser + Adapter(option) + Cable
Oil bottle capacity	100ML	Machine noise	≤30dB


06 Troubleshooting

Troubleshooting: *Please refer to the instructions below for diagnosis and attempt to repair before requesting a return to the factory for repair.

Fault Type	Troubleshooting	
The machine is not working	①Please check if the power adapter is DC5V-2A and if the DC end is correctly inserted? ②Is the working program set for the device currently in working hours?	
No mist, small mist	① Is the air pump working? ② Is there an airflow atomization core and oil suction pipe at the mist outlet Is the sealing ring of the loose or blocked air nozzle damaged or detached?	
Oil leakage	Is the essential oil bottle and atomization head tightened? Is the sealing ring of the atomization head deformed or damaged	
Abnormal noise	①The air pump is loose, so tighten the air pump. ② The air pump is damaged, so replace it with a new one.	

07 Attention

- Do not use overloaded power sockets, damaged power cords or adapters, otherwise it may endanger your safety. If found, please replace it in time to avoid fire hazards.
- If you are not a technician, please do not attempt to modify, disassemble, or repair the equipment to avoid damage.
- If there is an abnormality in the equipment, please check whether it operates according to normal usage requirements, or check according to troubleshooting. If it cannot be resolved, please contact the seller in a timely manner.
- When adding essential oil, please do not drop it into the equipment. The equipment should not be upside down or tilted during use.
- If the equipment needs to be transported to other sites, please first maintain and clean the equipment (see equipment maintenance for details) before packaging and transportation to avoid damage caused by essential oil infiltration.
- Please maintain and clean the equipment regularly to ensure that the equipment is in the best working condition.



Product model: MiniPlus

MANUFACTURED FOR: LÈLIOR GROUP LLC 1226 NW 23RD AVE FORT LAUDERDALE, FL 33311 INFO@LELIOR.COM



