


LÈLIOR
DE PARIS

INSTRUCTION



LI4000 Scent Diffuser User Manual

Introduction

This device, LJ4000, adopts two-fluid micro-nano atomization technology, with PCB intelligent program, which can be set by remote controller and APP. Using innovative noise-reduction design, with low work noise and it can be placed independently. The main function is to create various atmosphere of scenting for daily life, with modern look and wonderful diffusing performance, suitable for KTV, sales offices, shopping malls, 4S stores, home and SPA stores.

Attentions

Please read this manual in detail before using the device and keep it carefully.



1. Please do not use overloaded power sockets, broken wire and charger. It may endanger your safety and cause a fire, please replace in time if it happens.
2. Please do not try to modify, disassemble or repair the device in order to avoid damage to the device, if you are not a technician. If the device is abnormal, please check whether it is operated normally according to the user manual, or check according to the Malfunction Debugging. If it cannot be solved, please contact seller timely.
3. Please do not invert or tilt the device when used. If the device needs to be transported to other sites, please maintain and clean the device (see Maintenance for details) first before package and transportation, in case of oil leakage to damage the device.
4. Please maintain and clean the device regularly to ensure the device in best working states.

Instruction of Essential Oil








1. Before refill canister with essential oil, please turn off the device for 2 minutes till oil of atomizer back to canister then take off the oil canister.
2. It's recommended to control the amount of essential oil and run out within 45 days, in order to avoid the deterioration of essential oils by oxidation.

Parameters


Size	W195*D182*H664 (mm)
Capacity	1000ml
N.W	5.9KG
Coverage	2500 sqft
Voltage	DC12V-1A
Power	10W
Noise	≤41db
Package	W715*D225*H220 (mm)



Accessories

Item	Atomizer core	Seal ring	User manual	APP user manual	Remote controller manual
Diagram					
Item	Power adapter	Remote controller			
Diagram					

Installation



1. Open the cover to take out the oil canister and fill essential oil.
2. Install the atomizer with canister to the device, and close the cover.
3. Connect the device to DC12V power socket and start setting.

Setting

1. Power it on after connect with power socket.
2. Connect the WIFI on the phone(2.4G network band) and open the APP on the phone.
3. Press and hold the indicator button on the device for more than 5 seconds until the yellow light flash appears to enter the matching mode.
4. On the APP, click "Match" to enter the matching interface, select the WIFI name and enter password to connect, waiting for the connecting progress bar, then enter the name you want to set in the blank box that pops up, choose the model and click [√] in the upper right corner. Then Yellow light flashing, the device will appear on the main interface (refresh it by pulling down the main interface if it doesn't appear).
5. Indicator status display description:
 - a) Red: Stop;
 - b) Blue: Work;
 - c) Yellow light: matching indicator flashing yellow light: matching mode, constant yellow light: connected; light off: disconnected / offline;
 - d) Indicator combination description:
 - Yellow on + blue on: matching and working status;
 - Yellow on + red on: matching but stop / pause work status;
 - Yellow off + blue on: not matching but working status;
 - Yellow off + red on: not matching and pause / stop work status;
6. For the configuration and operation of the APP, please refer to the APP operation manual.
7. For the operation of the remote control, please refer to the remote control manual.

Tips

1. The time system is 24-hour, and the valid setting is 00:00-23:59. If the work period exceed 00:00, then it need to set into two work periods respectively. For example, if the ON time is 19:00 and OFF time is 03:00, then setting must be two work periods: 1st work period is 19:00-23:59; 2nd period is 00:00-03:00. The work period cannot be set repeatedly during same workday, otherwise the system will not recognize it.
2. Reset the default setting by pressing [MODE] for 10 seconds. Default Setting: 1st work period is 08:00-22:00, MON to SUN, SCENT WORK is 60 seconds, SCENT PAUSE is 60 seconds.

Maintenance

In order to ensure the best diffusing effect, please check and maintain the device every six month, or when you replace a new fragrance, or when the diffusing effect get weak as the following steps.

1. Take off the oil canister which is spent.
2. Filling industrial alcohol into the canister and clean it.
3. After clean the oil canister, refill canister with little alcohol and install it on the device then make the device stay in working status for 5-8 minutes.
4. Turn off the power when finishing cleaning.

Malfunction Debugging

Please try to solve the problem as below before fixing the machine.

Breakdown	Solution	Breakdown	Solution
Not working	<ul style="list-style-type: none">- Check if power adapter is DC12V-1A, and check if DC power interface is well-connected or not.- Check if device is not in work period.	Oil leakage	<ul style="list-style-type: none">- Check if oil canister connects to atomizer closely.- Check if seal ring is deformed or damaged.- Check if atomizer is damaged.
No mist Mist gets weak	<ul style="list-style-type: none">- Check if air pump works or not, and if airflow from air outlet.- Check if atomizer core and oil tube are loose or blocked.- Check if seal ring gets damaged or fall off.	Abnormal noise	<ul style="list-style-type: none">- Check if air pump is loose, please fix it correctly.- Check if air pump is damaged, please replace a new one.

After-sales Service

The warranty is 1 year from the date of sale, not including device shell, adapter, electric wires, seal ring and the other vulnerable parts, as well as the damage caused by human or accident. Permanent maintaining for value will be provided if the machine exceed the warranty.

If there is any issue of after-sales, please contact authorized sales service in corresponding area, or contact Sales Center directly.

Warranty Card

This card is the warranty for device's quality, please fill it with actual information.

Warranty card one		Warranty card two	
Start Date of Warranty Period		Start Date of Warranty Period	
Malfunction Description		Malfunction Description	
Date of Verify		Date of Verify	
Maintenance Result		Maintenance Result	
Maintainer's Signature		Maintainer's Signature	

Scan the QR code to download the APP

Go to Application Store to search for "Aroma World" to download APP.



English

LÈLIOR
DE PARIS

MANUFACTURED BY:
LÈLIOR GROUP LLC
1226 NW 23RD AVE FORT LAUDERDALE, FL 33311
INFO@LELIOR.COM



FOR MORE INFORMATION