Innovating Safety for Every Mile

WELLDON

Ningbo Welldon Infant And Child Safety Technology Co.,Ltd. www.welldon.com



COCOON TRAVEL 2 USER MANUAL



WD021

Digital Manual



This child safety seat complies with UN Regulation No. 129/03. Please read the full instructions carefully before installation and using this product.

Basic Information



COCOON TRAVEL 2 WD021

Basic Information



This high-back booster seat features a ISOFIX for easier installation, ensuring maximum safety and comfort for your baby during travel.

Recommended for:

Age: From 3 years to approx. 12 years Stature: 100-150 cm Only suitable for vehicle seats with automatic three-point belts approved by UN Regulation No. 16 or a comparable standard.

*ECE = European Standard for Safety Equipment

The child safety seat has been designed, tested, and certified according to the requirements of the European Standard for Child Safety Equipment (ECE R129). The seal of approval "E" (in a circle) and the approval number are located on the approval label (sticker on the child safety seat).

This approval will be invalidated if any modifications are made to the child safety seat. Only the manufacturer is permitted to make modifications to the child safety seat.

Forward Facing Only It is not recommended to install child safety seats in front seats with airbags.

Green colors indicate optional installation locations where a 3-point harness system is required.

It is recommended to install on the back seat.



Quick Installation Guide

Quick Installation Guide















Table Of Contents

1.Warning6
2.Product Description7-8
3.Installation With Booster Seat9-10
4.Removing The Seat11-12
5.Care And Cleaning13
6.Warranty14

READ USER MANUAL PRIOR TO INSTALLING AND USING THIS HIGH-BACK BOOSTER. KEEP INSTRUCTIONS FOR FUTURE USE.

1.Warning

- The rigid items and plastic parts of the high-back booster seat should be located and installed so that they are not likely to become trapped by a movable seat or in the vehicle's door during everyday use.
- 2. Any straps securing the restraint to the vehicle should be tight. Straps restraining the child should be adjusted to fit the child's body, and straps should not be twisted.
- 3. It is important to ensure that the lap straps are positioned lower than the baby's hips.
- 4. High-back booster seat should be replaced if it has been subjected to violent stresses in an accident.
- 5. DO NOT leave your child unattended in the booster seat.
- 6. Secure any luggage or other objects that could cause injuries in the event of a collision.
- 7. DO NOT use the booster seat without the fabric cover.
- 8. DO NOT replace the cover of the high-back booster seat with anything other than the one recommended by the manufacturer, as the cover is an integral part of the restraint system's safety performance.
- 9. Refer to the vehicle manufacturer's handbook for the use of an "i-Size ECRS".

2.Product Description

2.Product Description



- 1. Headrest
- 2. Seat Belt Retainer
- 3. Shoulder Belt Guide
- 4. ISOFIX Unlocking Button
- 5. ISOFIX Double-locking Button
- 6. ISOFIX Installation Indicator
- 7. Cup Holder
- 8. Backrest
- 9. ISOFIX Connect Locking Arms
- 10. Headrest Height Adjusting Handle
- 11. Side Wings Adjusting Handle





ISOFIX Releasing Handle
Recline Angle Adjusting Handle

ACCESSORIES



Cup Holder

ensures that both parents and children have easy access to beverages while on the move

ISOFIX Guide

Insert the ISOFIX Guides onto the car's anchors to attach the child seat securely.

Fabric Insert Tool

This fabric assist tool is designed to help with installing fabric covers.



Lumbar Cushion

providing lower back support during travel.

3. Installation With Booster Seat

3. Installation With Booster Seat













- Pull the ISOFIX releasing handle (12) to extend ISOFIX connect locking arms (9) to the maximum length automatically.
- Insert the ISOFIX connect locking arms (9) into the ISOFIX fixture points in the vehicle seat. Ensure that there is a "click" sound and a green indication on both ISOFIX connect locking arms (9).
- Pull the side wings adjusting handle (11) to adjust the size according to the car's interior situation and the child's size. It can also be adjusted on one side.
- Adjust the headrest (3) to the appropriate height according to the child's height.

Notice! Ensure the shoulder belt guide **(3)** is at the same height as the child's shoulders.

Pull the recline angle adjusting handle (13) to adjust the back of the seat to different angles.

Adjust the seat into proper position before fastening the belt on the child (there are 4 positions).

Disengage the seat belt retainer (2). Thread the seat belt through the shoulder belt guide (3) of the booster seat. After ensuring the seat belt is correctly fastened on the booster seat, lock the seat belt until you hear a "click."

CAUTION! DO NOT twist the seat belt.

4. Removing The Seat







4. Removing The Seat

- Unfasten the seat belt, ensuring the belt is removed from the shoulder belt guide (3).
- Press the ISOFIX unlocking button (4) and the ISOFIX double-locking button (5) simultaneously. When the ISOFIX installation indicator (6) shows red, it means the ISOFIX connecting arms (9) are disconnected from the fixture points.
- Pull the ISOFIX releasing handle (12) and push the ISOFIX connecting arms (9) into the booster seat .

5. Care And Cleaning

IMPORTANT USAGE INSTRUCTIONS

- **1** Airbag Usage: For correct usage of the airbag in combination with the seat, read the vehicle handbook.
- **2** Indicator Check: Ensure the indicators are green before you drive.
- Seat Positioning: Make sure the back of the seat is touching the backrest of the vehicle seat and the ISOFIX connectors are pushed inside the seat as far as possible. The red surface on top of the ISOFIX release handle must not be visible during driving.

CLEANING



WARNING! Please be sure to use only the original cover, as the cover is crucial for the secure operation of the system. Replacement seat covers are available from your retailer, agent, or the manufacturer.

The high-back booster seat must not be used without the cover.

- The cover can be removed and washed in a washing machine at 30°C with neutral detergent. Please read the washing label on the cover carefully before washing.
- Do not wash the cover at temperatures above 30°C, as the color may fade. Do not wring or iron the cover, as this may cause the fabric to separate from the padding.
- The plastic parts of the seat can be cleaned with soapy water. Do not use strong detergents (such as solvents).

6. Warranty

We provide a 7-year warranty for this infant carrier against manufacturing or material defects. The warranty period begins on the date of purchase. To validate the warranty, please keep the invoice and register your product on <u>welldon.com</u>.

The Warranty Does Not Cover:

- Natural signs of wear and damage resulting from excessive stress.
- Damage resulting from inappropriate or improper use.
- Color fastness may diminish when exposed to UV radiation. However, all fabrics fade when exposed to UV radiation. This is not a material defect but a normal sign of wear that is not covered by the warranty.
- Buckle malfunction is often due to the accumulation of dirt and dust, which may prevent it from working properly. If this occurs, please check if you can clean it yourself without damaging the installation. If cleaning does not resolve the issue, please contact after sales service.

For warranty claims, please contact your retailer directly. They will provide the necessary advice and support. When processing claims, product-specific depreciation rates will be applied. Please refer to our General Terms and Conditions, which are available from your retailer.