HOME CREATOR

Installation Guide Level 2 Roller Blinds

www.homecreator.com.au



www.homecreator.com.au

Level 2 - Roller Blinds Installation Guide









Idle End Bracket

Clutch Bracket

Idle End Plug

Clutch

- To confirm the position where roller blinds is fitted, recess fitting or face fitting.
- To confirm the position where Clutch (chain position) is fitted.







Clutch to Clutch bracket



Idle End Plug to Idle End bracket



Fit Clutch bracket



Measure the blinds width,



Insert clutch side into



Insert idle end plug into

fit Idle end bracket on the other side.

clutch bracket


idle end bracket



Using sprit level to check

Rolling control chain to put blinds down

if the blinds fitted on the same level



• To fix Child Safety Device

Our blinds are provided as standard with a compliant child-safety device, which must be installed.

The chain is less than 1500mm from floor level, safely preventing any risk of accidental strangulation.

- 1. Hole the device against the wall and mark the location of the screw hole.
- 2. Attach our cord guide on the chain and fix the device to the wall.