


HOME CREATOR




Installation Guide Level 1 Roller Blinds

www.homecreator.com.au



Level 1 - Roller Blinds Installation Guide




Idle End Bracket Clutch Bracket Idle End Plug Clutch Safety Hook Screw

- To confirm the position where roller blinds is fitted, recess fitting or face fitting.
- To confirm the position of Clutch where the chain is fitted.



Fitting Position



Clutch to Clutch bracket, Idle End Plug to Idle End bracket



Fit idle end bracket



Measure the blinds width,



Fit idle end plug into tube



Fit clutch side into tube

Fit clutch bracket on the other side.

adjust it on the proper position



Push idle end plug into the idle bracket



Fit clutch into the clutch bracket



Using spirit level to check if the blinds is on the same level



Proper position



Put caps on brackets



- To fix Child Safety Device

Our blinds are provided as standard with a compliant child-safety device, which must be installed.

The chain is less than 1500mm from floor level, safely preventing any risk of accidental strangulation.

1. Hole the device against the wall and mark the location of the screw hole.
2. Attach our cord – guide on the chain and fix the device to the wall.