

STANDARD FRONT HUB

The standard front wheel can be fitted in either orientation; the axle is symmetric. A tab washer and M8 washer should be fitted on each side between the fork leg and axle nut (fig. 1) making sure that the special tab washer (TW) is fitted on the left hand side to engage with the mud-guard stay. The axle nuts should be tightened to 15Nm, while making sure the wheel is central between the fork legs.

