

Blind size measuring

1 WIDTH

The actual width of the blind from the outside edge of the brackets or head-box. Be mindful of any wide tiles or skirting boards which intrude into where the blind fabric might fall. If you need to make adjustments for skirting or tile intrusion, please note that the standard distance from the edge of the fabric to the outside of the bracket is 25mm on each end. If you require more space to allow the fabric to fall correctly, please adjust your measurements accordingly.

2 BLIND DROP

The total drop of the fabric measured from the top of the bracket (*window reveal) to the window sill or the floor.

3 HEIGHT FROM GROUND

This measurement is from the top of the bracket (*window reveal) to the floor. (This is to determine chain length for child safe regulations and so you can operate the blind easily should the window be high up).

