ANDINO




Ready to use? Just remember the following:

- 1. Do not touch if it is hot.
- 2. Do not start a fire in places that are not allowed or where there is a risk of fire.
- 3. Do not start fire if the 4 legs are not well placed.
- 4.The paint will be removed with use, this is a natural part of use and is not deterioration.

Zonda 45

Instructions manual







Index

- 1-Opening
- 2-Unboxing with special handles
- **3-Screwing and Legs assembly**
- 4-Door and smoker handles
- 5- Wooden board & cross
- 6- Griddle and grills

Curing

Prior to the first use of the grill, unpainted parts must be cured. This is a simple process that consists of 3 steps and requires 3 elements:



1. Cooking oil or grease



2. Cloth or paper




3. Heat source


- Wash the iron piece before beginning the curing process.
- Apply a thin film (small amount) of oil on the material, spread it well with the paper, and then clean the piece with a dry cloth.
- Expose the piece to the heat of the stove, oven or direct flame for a few minutes or until you notice that the material begins to darken.

Repeat last two steps if necessary

Opening


Product arrives like this, on a wooden box. Proceed to remove the lid.






Continue taking out grill and pick up the handles.






Unboxing

Check how handles are mounted over sides of the Zonda.






Please notice that there are specific slots to fit the handle.




Hold the handles tight once they are in place and pull up.

Griddle & Grills


1 The use of the grill or the griddle are the choice of each cook.





Clamp Rack

The clamp rack works as a press. You need one of the product's grills, it must first be placed underneath and then closed with the rod.




10° 30° 60°

It can be used in 3 different positions depending on the thickness of the food being pressed.


And heat needed.






Legs assemble

Face down Zonda and then, one by one, grab and mount the legs. Check legs are first screwed in one pice (a & b).




Each leg needs to be screwed into a nut.






Aluminium Handle


There is one aluminium handle screwed inside the door, you need to unscrew it and place it on the outer side.






Use correct Phillips screwdriver for operation.






Board & Cross

The wooden board can be mounted either on right or left hand of the grill.



Use she specific slots for this step.



Below the board are the "arms" where you can place the shovel and/or poker at rest.

