



Use and Care Instructions

PLEASE READ USE AND CARE INSTRUCTIONS IN ITS ENTIRETY
PRIOR TO SETTING UP AND OPERATING YOUR RETROLIFE PRODUCT

NOTE: As with any electronics maintenance, always unplug the unit from the power outlet to prevent the risk of electrical shock.

The Retrolife R612 is an entry-level split record player, paired with a pair of 30-watt bookshelf speakers to bring you an excellent music experience. In order to ensure that you can enjoy the wonderful music brought by this turntable for a long time, here are some suggested use and maintenance methods:

1.Placement:

Place the R612 turntable and bookshelf speakers on a solid surface to ensure they are balanced and stable. Avoid placing the device in direct sunlight, high temperature, humid or dusty environment to protect its appearance and internal structure.

2.Using the stylus:

Please make sure the stylus is in good condition before use, avoid using old and worn stylus, so as not to cause damage to the record and affect the sound quality. Check the stylus regularly for wear and replace as necessary.

3.Record storage:

Before playing the record, please check whether the record is clean, if there is dust or dirt, use a professional record cleaning tool to gently clean it. When you're done playing, store your records in their sleeves or racks out of direct exposure to dust and sunlight.

4.Adjusting the RPM:

The R612 supports playback speeds of 33 $\frac{1}{3}$, 45, and 78 revolutions per minute (rpm). When playing records with different RPM, make sure to adjust the RPM switch to match the record's requirements for the best sound quality.

5.Cleaning and Maintenance:

Regularly clean the exterior surfaces and acrylic covers of vinyl record players and bookshelf speakers, and wipe them with a soft, clean cloth, avoiding the use of cleaners containing alcohol or corrosive substances.

6.Volume control:

R612 is equipped with a pair of 30-watt bookshelf speakers. Please avoid excessive volume for a long time to protect the speaker and your hearing.

7.Avoid overuse:

While the R612 is designed to be durable, to prolong its life, avoid overuse of turntables and bookshelf speakers. After each use, please turn off and unplug the power plug.

8.Maintenance of the power cord:

Regularly check whether the connection of the power cord is firm, and avoid the power cord from being stressed or twisted to ensure safe use.

Follow these usage and care recommendations and you'll be able to enjoy the superior music experience of the Retrolife R612 for a long time to come. Make this entry-level split turntable with speakers a powerful addition to your music life.

Retrolife offers a product line of various cleaning accessories. Please visit our website at <https://retrolifeplayer.com/collections/accessories> for more information. As products are improved and new products are released, our Use and Care Instructions are regularly updated on corresponding pages and <https://retrolifeplayer.com/pages/help-center>