65.0 mm x 90.0 mm

URB/N



Quick Start Guide


Thank you for choosing the "URBAN Vibe" to better use this product, please read the quick start quide carefully before use and properly manage it.

Product Specifications

Product Name URBAN Vibe Driver Diameter 1/1/3 5.3V RT Version-RT Pange Sensitivity: 115.5 +3dB Charging Type: Type C Charging Time: Unto 1-2 Hours 75 mAh Battery Capacity Play/Talking Time Upto 15 hours IPX6 IPX Rating:

Chipset: Qualcomm CVC 8.0 100am(15am product)

Product Diagram



- (1) Type C Port
- (2) Multi Function Button(MFB)

3 LED Indicator

How to Use

Power On: Long press the MFB button for about 2 seconds.

and the blue light will start flashing three times indicating the URBAN Vibe earphones

are ready to use

Power Off: Long press the MFB button for about 4 seconds,

while switched on, A red indicating light, will flash three times before turning off

Press and hold the MEB button for about 4 Pairing: seconds, red and blue lights will flash

alternately, indicating the URBAN Vibe

earphones are ready to pair

Short Press the MFB button once, to answer Anewor/ an incoming call While on call short-press hang up a call:

the MFB to hang up the call

Press and hold the MFB button for about Reject a call

2 seconds

Short press the MFB button once to play Play & pause

a song: and pause the music

Next song: Long Press the MFB button 2 times in

quick succession

Voice Assistant: On switch-on mode, long-press the MFB button

for about 2 seconds on standby to activate the voice assistant on your phone.



Light Indicator

Low Battery Reminder: Out of Range Reminder: **Device Charging:** Fully Charged:

Blinking Red Light Blink Red Light With Sound Continuous Glowing Red light Continuous Glowing Blue Light

How To Pair

- · When using for the first time or pairing a new device, long press the MFB for 4 seconds, and a combination of red and blue lights will start flashing alternatively indicating the earphones are now ready to be paired
- · Now open the Bluetooth on your phone or any other pairing device and search for URBAN Vibe
- On finding the name on the pairing list of the device, tap to connect
- · After successfully pairing the earphones with your device for the first time, the earphones will seamlessly connect with the paired device automatically when you switch it on to use

• URBAN Vibe comes with a dual pairing option and lets you connect 2 devices simultaneously and toggle between both devices seamlessly. Once the first device is paired, switch off the Bluetooth connectivity of device 1; then repeat the previous steps with device 2.

Precautions

- The charging voltage cannot exceed 5 Volt to prevent overheating & short-circuit
- · URBAN Vibe has air conduction technology hence should be placed closer to your ears as per your convenience but not on the ears
- · Do not let children play with the headphones, small parts may put children have risk of suffocation.
- · Before boarding, please turn off the headset
- · To better protect your hearing, do not adjust the volume too loud.
- · Do not attempt to make any modifications or disassembly of this headset.

- · Do not use this product in wet or rain.
- · not clean the headphones while in the charging state

Troubleshoot

Heard the sound of [Kaka]

Your URBAN Vibe Open earphones have a Bluetooth range of 10 Meters, when you move away from the range, might experience this sound to indicate it, try keeping your earphones and device closer

Do earphones have no sound?

- · Make sure the earphones is charged.
- · Check the phone if you have put it on mute
- · Restart if the problem persists
- Contact the URBAN Customer Support Team if the issue

The phone is not connected to the earphones?

- Make sure you are connecting to the previously paired device/ phone
- Make sure your phone's Bluetooth device is enabled.
- Mak sure the headset is within 10 meters of the phone
- Try resetting the pairing option and re-pair the device



gourban.in