

TireView® TPMS IN-CAB DISPLAY: DRIVER REFERENCE

DISPLAY ALERTS

The display will cycle through each of the tire positions, showing pressure and temperature. In the event of an alert an audible alarm will sound, the red LED will flash, and the display will indicate which tire is at risk.

NOTE: The audible alarm can be silenced for a short while by pressing any of the buttons on the front of the display. The display will continue to cycle through all tire positions.

NOTE: The (!) icon will stay on screen and the red warning light will continue to flash until the issue is resolved.

Fast Leak Alert


NOTE: A fast tire leak is a loss of 2 PSI or more in less than one minute.

- The red LED will flash.
- 2. (!) & FAST LEAK will be displayed.
- 3. The pressure and tire position will be identified.

Red LED


Low Pressure Alert

- 1. The red LED will flash.
- 2. (!) & LO PRESSURE will be displayed.
- 3. The pressure and tire position will be identified.



High Pressure Alert

- 1. The red LED will flash.
- 2. (!) & HI PRESSURE will be displayed.
- 3. The pressure and tire position will be identified.







TireView® TPMS IN-CAB DISPLAY: DRIVER REFERENCE

DISPLAY ALERTS (continued)

High Temperature Alert

- The red LED will flash. 1.
- (!) & HI TEMP will be displayed. 2.
- 3. The temperature and tire position will be identified.





- 1.
- 2.
- 3.





CUSTOMER SUPPORT INFORMATION:

WEB: www.psitireinflation.com **EMAIL:** techsupport@psitireinflation.com

PHONE: (210) 222-1926