



QUICK START GUIDE



QUICK START GUIDE

- Remove the HR500 from the packaging and remove the battery. The battery has a label protecting the contacts. REMOVE THE LABEL AND DISCARD.
- Remove battery charger from packaging and Plug in.
- 3. Place battery into the battery charger until the LED turns green. The area in which the batteries are charging and the batteries themselves must be above 55° F or battery may not charge or may take longer to charge. Recommended temperature for battery charging is 55° to 85° F. When battery is fully charged, remove the battery from the charger and place into the battery slot located on the bottom of the HR500 unit, making sure the battery is fully inserted.
- 4. Press Power button to turn HR unit on.
- The HR500 always starts in Standard Mode (STD). Use the Mode button to change between Modes.







For additional information visit: www.ozonicshunting.com

