

# T30 & T10 Remote Controller

April 2024

**RANTIZO**<sup>®</sup>

Confidential: Do Not Distribute




# Remote Controller (RC) Part 1A




# RC Part 1B

No.	Material Number	Material Name
1	YC.SJ.WS001857	Antenna Right Sleeve
2	YC.DZ.AA000151	Transmission Antenna (Left) (Short)
3	BC.MA.SS000067	Left Dial Module
4	YC.JG.ZS000342	Remote Controller Front Cover
5	YC.WJ.L01124	T16-PC030030-30-34
6	YC.WJ.SZ000014	Outlet Dustproof Mesh
7	BC.MA.SS000068	Right Dial Module
8	YC.JG.MY000116	USB Dustproof Rubber Stopper
9	YC.SJ.WS001865	Front Cover Air Outlet Decorative Piece
10	YC.JG.MY000117	HDMI Dustproof Rubber Stopper
11	YC.SJ.WS001859	Front Cover Decorative Piece
12	YC.WJ.L01124	T16-PC030030-30-34
13	YC.SJ.WS001864	Light Guide Beam
14	YC.JG.MY000086	Front Cover Rubber Plug
15	BC.MA.SS000071	Right Control Stick Module
16	YC.WJ.RR000059	Heat Sink
17	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi 1.6 \times 34$
18	YC.JG.MY000152	PCBA Decorative Cover
19	YC.DZ.AA000081	Wi-Fi Antenna 2
20	YC.DZ.AS000004	Speaker
21	YC.DZ.AA000080	Wi-Fi Antenna 1
22	YC.DZ.PF000239	Right Hall Sensor Board Flat Cable
23	BC.AG.SS000397	Remote Controller Image Transmission Board
24	YC.SJ.MQ000051	Battery Cable Mounting Piece
25	YC.WJ.L00018	IMU Screw M1.6*3.5
26	YC.DZ.BB000052	Remote Controller Built-in Battery
27	YC.PM.QT000064	Mounting Piece Foam
28	YC.SJ.WS001879	Video Downlink Antenna Mounting Piece
29	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi 1.6 \times 34$
30	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi 1.6 \times 34$
31	YC.JG.FM000003	Remote Controller Lanyard
32	BC.EN.SS000375	Remote Controller Lower Shell Module
33	YC.JG.MY000074	Remote Controller Soft Rubber (Right)
34	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi 1.6 \times 34$




# RC Part 1C

No.	Material Number	Material Name
35	YC.JG.MY000075	Remote Controller Soft Rubber (Left)
36	YC.DZ.MD000024	Vibration Motor
37	YC.DZ.AF000059	Fan
38	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi$ 1.6X34
39	YC.JG.ZS000173	Fan Bracket
40	YC.WJ.L01491	T16-PP036036-28-11 V2
41	BC.EN.SS000374	Remote Controller Fan Cover Plate Module
42	YC.WJ.CC000093	Antenna Rotational Bracket
43	BC.MA.SS000084	Antenna Base Module
44	YC.SJ.WS001861	Antenna Bracket
45	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi$ 1.6X34
46	YC.SJ.WS001862	Antenna Left Sleeve
47	YC.DZ.AA000150	Transmission Antenna (Right) (Long)
48	BC.RM.PP000081	Right Hall Board
49	BC.RM.PP000080	Left Hall Board
50	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi$ 1.6X34
51	BC.MA.SS000070	Left Control Stick Module
52	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi$ 1.6X34
53	YC.DZ.PF000240	Left Hall Sensor Board Flat Cable
54	YC.BZ.J00931	Flat Cable Base Sticker
55	YC.BZ.J00931	Flat Cable Base Sticker
56	BC.AG.SS000234	Remote Controller Button Board
57	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi$ 1.6X34
58	BC.AG.SS000394	Remote Controller Main Board
59	YC.DZ.PF000234	Main Board and Combination Buttons Board Flat Cable
60	BC.RM.PP000084	Photosensitive Board
61	YC.SJ.WS001872	Main Board Mounting Piece
62	BC.RM.PP000086	SDR Board Flat Cable
63	YC.SJ.WS001872	Main Board Mounting Piece
64	YC.SJ.WS001872	Main Board Mounting Piece
65	YC.SJ.WS001871	RTH Button
66	YC.SJ.WS001880	Power Button
67	YC.JG.ZS000949	Spraying Button
68	YC.XJ.QT000108	Upper Shell Button Silicone Rubber Gasket



# RC Part 1D

No.	Material Number	Material Name
69	YC.WJ.TT000140	Shutter Button Spring
70	YC.SJ.WS001883	Flight Mode Switch
71	YC.SJ.WS001881	5D Button
72	YC.JG.ZS000369	Pause Button
73	YC.XJ.QT000110	Button Round Gasket
74	YC.SJ.WS001876	Return/Function Button
75	BC.AG.PP000272	Spraying Button FPC
76	YC.WJ.LL000387	T16PC004000400300080323N
77	BC.AG.SS000396	Remote Controller Upper Shell Module
78	BC.RM.PP000087	Left Dial Board (RH)
79	YC.WJ.L00158	Cross-headed Self-tapping Screw (Thin) $\phi$ 1.6X34
80	YC.JG.ZS000954	Shutter Button
81	YC.SJ.WS001877	Confirm Button/Customizable Button C3
82	BC.AG.PP000271	Shutter Button FPC
83	BC.RM.PP000089	Right Dial Board (RH)
84	YC.JG.MQ000253	MIC Board Conductive Foam
85	YC.JG.MQ000253	MIC Board Conductive Foam
86	YC.PM.DD000036	Main Board Conductive Foam
87	YC.PM.DD000037	Screen Conductive Foam
88	BC.AG.SS000393	Microphone Board
89	YC.PM.QT000043	Heat Sink Shielding Piece
90	YC.JG.MQ000560	Image Transmission Board Foam
91	YC.XJ.QT000106	5D Button Decorative Silicone Rubber
92	YC.JG.MY000076	Control Stick Dustproof Ring
93	YC.DZ.EE000022	Touchscreen
94	YC.PM.QT000065	Battery EVA Foam
77&93	BC.AG.SS000395.01	Remote Controller Upper Shell Module(Including screen)




# Remote Controller (RC) Part 2A




# RC Part 2B

No.	Material Number	Material Name
1	YC.SJ.WS003418	Remote Controller Extension Module Middle Frame
2	YC.WJ.LL000345	M40-HC01600140-072040-0323-Y
3	YC.SJ.WS003416	Dongle Cover (Extension Module Upper Cover)
4	YC.JG.MY000073	Extension Module Bottom Pad
5	YC.PM.QT000191	Upper Cover Compressing Foam
6	YC.PM.QT000192	Middle Frame Compressing Foam
7	YC.JG.TT000047	Remote Controller Battery Spring Block Compression Spring
8	YC.WJ.L00556	T16-PP030030-45-24
9	YC.WJ.ZZ003741	Port Board Heat Sink
10	BC.AG.SS000398	Remote Controller Expansion Board
11	YC.WJ.L00556	T16-PP030030-45-24
12	YC.WJ.TT000091	Remote Controller Battery Power Button Spring
13	YC.JG.ZS000945	Remote Controller Battery Release Button
14	YC.JG.MQ000112	Microphone Port Dustproof Foam
15	YC.JG.ZS000946	Remote Controller Battery Cable Cover
16	YC.PM.QT000203	Back Board Foam Glue
17	YC.WJ.LL000387	T16-PC00400040-030008-0323-N
18	YC.JG.ZS000951	Remote Controller Expansion Kit Bottom Cover
19	YC.WJ.L00178	M4 Locknut
20	YC.WJ.ZZ003739	Extension Module Handle
21	YC.WJ.L00418	Hexagon Socket Full Thread Screw M3x12
22	YC.WJ.ZZ003740	Mounting Piece on the Extension Module
23	YC.JG.ZS000952	Remote Controller Battery Cover Switch Shielding Piece
24	YC.JG.ZS000955	Remote Controller Battery Cover Switch
25	YC.WJ.LL000387	T16-PC00400040-030008-0323-N
26	YC.WJ.LL000387	T16-PC00400040-030008-0323-N
27	BC.AG.SS000399	Remote Controller Expansion Module Battery Port Board
28	YC.JG.MQ000112	Microphone Port Dustproof Foam
29	YC.JG.TT000038	Battery Cover Spring
30	YC.JG.LD000029	Remote Controller knurling Shaft
31	YC.JG.ZS000950	Remote Controller Battery Compartment Cover
32	YC.BZ.TZ000106	Fan Cable Fixing Sticker



# RC Part 2C

No.	Material Number	Material Name
33	YC.PM.DD000070	Thermal Conductive Foam
34	YC.XJ.QT000214	Avionics Antenna Fixing Rubber A
35	YC.PM.DD000077	Conductive Foam (Long)
36	YC.JG.MQ000249	Dongle Fixing Foam





# T30 & T10 Remote Controller



# Contact Support

---

## Web

[www.Rantizo.com](http://www.Rantizo.com)

---

## Email

[Support@Rantizo.com](mailto:Support@Rantizo.com)

---

## Phone

(319) 201-3020 (ext. 2)

---

## LinkedIn

[@RantizoSprays](#)

---

## Facebook

[@RantizoSprays](#)

---



# Thank you.

---