



H A Y L O U

HAYLOU G3

真无线蓝牙游戏耳机

使用说明书

01 蓝牙配对

配对模式

1. 打开充电盒上盖，耳机进入配对模式。
2. 在移动设备中，新增蓝牙设备列表处
搜寻蓝牙配对名 " Haylou G3 "，点
选完成配对。
3. Haylou G3耳机完成配对。



02 触摸功能








基本控制

按住 2 秒		开机*
按住 10 秒		关机**

* 当充电盒打开时，Haylou G3耳机将自动开机





** 将Haylou G3耳机放入充电盒并合上盖子时会自动关机

音乐播放控制

短按 1 次		播放 / 暂停
左耳短按 2 次		切换上一曲
右耳短按 2 次		切换下一曲
左耳长按		进入 / 退出游戏模式*
右耳长按		音乐 / 影院模式

* 退出游戏模式后才能使用音乐 / 电影模式切换

来电控制

短按 1 次		接听来电
短按 1 次		挂断电话
短按 2 次		来电拒接
短按 2 次		切换第三方通话

耳机重置

1. 耳机放回充电盒，保持耳机电量充足；
2. 双耳长按10秒关机，桃红色灯光闪2次后松开；
3. 再次长按5秒，长按期间会有其他灯效闪烁请勿松开，5秒后完成重置桃红色灯闪2次；
4. 重置后关闭充电盒，耳机呼吸灯亮起后，再次打开连接配对即可；

*若操作不成功，请重复上述步骤；或登录官方旗舰店，联系客服，查看复位操作视频。

03 指示灯状态



配对模式	黄色、桃红色灯光交替闪烁
开机	冰蓝色灯光闪烁3次
配对成功，连接行动装置	黄色灯光闪烁
播放音乐（音乐 / 影院模式中）	黄色呼吸灯效
游戏模式	绿色呼吸灯效
电量不足（低于10%）	红色灯光周期性闪烁
充电盒关闭，耳机充电中	黄色呼吸灯效
耳机充电完成	灯光熄灭

04 充电盒



指示灯

充电盒电量显示

4阶段呼吸灯效显示

电量不足(低于10%)

打开盒盖时, 充电盒指示灯闪烁3次

充电盒充电中

流水灯效实时显示电量

充电盒充电完成

灯光熄灭

05 充电

1. 请使用随附的充电线将Haylou G3充电盒连接到电源。
 2. 耳机和充电盒应在大约 2 小时内充电完成。
 3. 耳机充满电可播放 4 小时以上。
 4. 耳机配合充满电的充电盒使用可播放长达 20 小时。
 5. 耳机需放入充电盒内, 关闭盒盖后开始充电。
- *请务必在充电前去除耳机上的充电绝缘膜。

警告: 本产品中包含的可充电电池必须妥善处理才能回收。请不要将电池投入火中, 以免发生爆炸。

建议: 为了保持本产品锂电池的良好性能, 即使不使用也应每三个月充电一次。

06 规格参数

品牌名称: HAYLOU

产品型号: G003

产品描述: 真无线蓝牙游戏耳机

蓝牙配对名: Haylou G3

蓝牙版本: 蓝牙5.2

音效模式: 游戏/音乐/影院

低延迟: 45ms*

频率响应: 20Hz - 20,000Hz

喇叭参数: 13mm 复合式振膜高动态驱动单元

充电时间: ≤ 2 hours ,耳机与充电盒各别需充电时间

耳机电池容量: 45 mAH

充电盒电池容量: 500 mAH

包装内容物: 充电盒、耳机、充电线、使用说明书



CMIIT ID:2022DP7348

FCC ID:2AMQ6-G003

* 根据不同仪器以及不同方法测试的数据会产生差异, 此数据由AudioPrecision内建蓝牙盒子测试数据。

07 常见解决方案

问题	解决方案
我的G3无法充电	<ul style="list-style-type: none">• 将 USB-C（较小端）连接器牢固插入充电盒背面的充电端口。并确保 USB-A（较大端）连接器连接到电源。• 确保充电线两端连接正确。• 如果您的Haylou G3暴露在极端温度下，请等待它恢复到室温后再充电。
手动重启蓝牙功能后，我的G3无法再次自动与我的移动设备配对	<ul style="list-style-type: none">• 手动重启移动设备蓝牙后，需要手机自带回连功能，耳机不会主动发起回连。
我的G3没有声音	<ul style="list-style-type: none">• 增大耳机和移动设备的音量。• 确认连接的移动设备，确保使用的是正确的设备。• 使用不同的音乐来源。• 确保设备设置为使用蓝牙播放。• 配对另一个移动设备。• 如果连接两台移动设备，请暂停第一台移动设备的音讯，然后从另一台移动设备播放音讯。• 将移动设备移到耳机蓝牙范围内(10米)。

08 注意事项

警告

- 1、请勿以任何理由拆开、维修或改装耳机，否则可能会导致起火甚至彻底损坏本产品。
- 2、请勿将设备置于温度过低或过高（0℃以下或45℃以上）的环境下。
- 3、使用产品指示灯时，请避开儿童或动物的眼睛。
- 4、请勿在雷暴天气下使用本产品，雷暴可导致设备工作异常，并增加触电的危险。
- 5、请勿使用酒精或其他挥发性液体擦拭本产品。
- 6、请勿将本产品与液体接触。

注意

- 1、使用产品前请仔细阅读本使用说明书并请妥善保管。
- 2、首次使用时，请先将本产品充满电。
- 3、如果产品长期(超过2个星期)不用，请对其充电。
- 4、必须选择正规厂家生产且经过国家CCC认证的充电器。
- 5、长时间连续使用耳机有损听力，请合理控制使用时间及音量。
- 6、使用耳机会降低对外界声音的感知力，请不要在可能威胁到安全的环境中使用耳机。

09 有毒有害物名称及含量标识

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
耳机主体	×	○	○	○	○	○
充电盒	×	○	○	○	○	○
充电线	×	○	○	○	○	○
电池	×	○	○	○	○	○
耳塞	○	○	○	○	○	○

本表格依据SJ/T 11364 的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。



1、本标识内的数字表示产品（除电池外）在正常使用状态下，环保使用期限为10年。



2、本标识内的数字表示电池在正常使用状态下，环保使用期限为5年。

部件上的环保使用年限标识优先于产品上任何与之相冲突或不同的环保使用期限标识。本产品所有环保使用期限是指在产品说明书规定的使用条件下使用本产品不发生有毒有害物质泄露的安全年限。

10 Haylou蓝牙耳机售后服务

Haylou蓝牙耳机售后服务承诺:严格按照《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务,服务内容如下:在三包有效期内,您可凭购物凭证依照本规定享受免费的修理、更换、退货的权利。

- 1、自您购买之日起7日内,本产品出现故障,经由Haylou售后服务中心确定为产品质量问题,可享受修理、更换、退货的服务。
- 2、自您购买之日15日内,本产品出现故障,经由Haylou售后服务中心确定为产品质量问题,可享受修理或更换的服务。
- 3、自您购买之日起12个月内,本产品出现故障,经由Haylou售后服务中心确定为产品质量问题,可享受修理的服务。

三包凭证

产品型号				
用户信息	用户姓名		购买日期	
	联系电话		邮政编码	
	用户地址			
购买信息	销售单位			
	订单编号			

11 Haylou G3 性能故障表

名称	性能故障
蓝牙耳机	1. 使用过程中听不到声音。2. 通话过程中，对方听不到声音。 3. 无法充电。

非保修条例

- 1、使用造成的正常磨损脏污如：刮痕、颜色改变；因接触化学试剂、接触尖锐物体、掉落挤压等人为导致损坏。
- 2、未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动、不正确的使用非本产品配件或撕毁、涂改标贴、防伪标记。
- 3、已超过三包有效期。
- 4、因不可抗力造成的损坏。
- 5、不符合《性能故障表》所列性能故障的情况。
- 6、因人为原因导致本产品及其配件产生《产品性能故障表》所列性能故障。

说明书中的产品、配件、用户界面等插图均为示意图，仅供参考。由于产品的更新和升级，产品实物与示意图可能略有差异，请以实物为准。

12 售后服务与支持

保修期:

自产品购买之日起12个月(请妥善保管购买凭证)

免费服务:

在产品保修期内, 凡属产品本身质量引起的故障, 请用户凭购买凭证与经销商取得联系以享受售后服务。

如有任何产品损害或瑕疵非可归责于产品质量本身, 则不在保修范围内。有下列情形者不属于保修范围内:

- 1、因天灾、地震、雷击、异常电压、环境因素而发生之故障或毁损的。
- 2、自行或委托未经原厂授权维修之厂商拆卸、改装或更换非原厂零件。
- 3、未按使用手册操作或因人为使用不当而造成损坏者, 如产品浸水、腐蚀、掉落、挤压或露在异常温湿度环境下。

制 造 商: 东莞市猎声电子科技有限公司
制造商地址: 广东省东莞市南城街道宏图路
86号1栋401-410室
网 址: www.haylou.com
客 服 电 话: 400-855-5083




Haylou 微信公众号


01 Bluetooth Pairing

Pairing Mode

1. Open the lid of the charging case, the earphones enter pairing mode.
2. Select "Haylou G3" on the new Bluetooth device list and tap it to pair.
3. Haylou G3 is now paired.



02 Touch Sensor








Basic Control

Press for 2 secs		Power ON*
Press for 10 secs		Power OFF**

* Haylou G3 will automatically power ON when the charging case is opened.





** Put the earbuds into the charging case and close the lid, they will automatically power off

Playback Control

Tap once		Play/pause
Double tap the left earbud		Skip track backward
Double tap the right earbud		Skip track forward
Press and hold the left earbud		Enter/exit gaming mode*
Press and hold the right earbud		Music/cinema mode

* You can only switch between Music/Cinema Mode after turning OFF Gaming Mode.

Call Control


Tap once		Answer an incoming call
Tap once		Hang up a call
Double tap		Reject an incoming call
Double tap		Switch a third-party call

Restore Factory Settings

1. Put the earbuds back into the charging case and ensure the earbuds have sufficient power;
2. Press and hold both earbuds for 10s to power off, then release after LEDs flash rose red twice;
3. Press and hold again for 5s; please do not release when LEDs flash other color during the process; after 5s, LEDs flash rose red twice and the reset is completed;
4. Close the charging case after reset; open the charging case again to pair after the breathing lights of the earbuds are on;

*If the operation is unsuccessful, please repeat the above steps; or log in to the official flagship store, contact customer service, and view the reset operation video.

03 Led Status



Pairing mode	Flash yellow and rose red alternately
Power on	Flash blue 3 times
Pairing is successful, connect the mobile device	Flash yellow
Play music (in music/cinema mode)	Yellow breathing light effect
Gaming mode	Green breathing light effect
Low battery (less than 10%)	Flash red periodically
The charging case is closed and the earbuds are charging	Yellow breathing light effect
The earbuds are fully charged	LED goes out

04 Charging Case



LED indicator

Power display of charging case	4-stage breathing light effect display
Low battery (less than 10%)	When opening the lid, LED of the charging case flashes 3 times
Charging case is charging	The running water light effect displays the power in real time
The charging case is fully charged	LED goes out

05 Charging

1. Connect the Haylou G3 charging case to a power source with the provided charging cable.
 2. The earbuds and the charging case should be fully charged in around 2 hours.
 3. More than 4 hours of playtime when fully charged, up to 20 hours of playtime with a fully charged charging case.
 4. Put the earbuds into the charging case, and they will start charging after closing the lid.
- *Please make sure to remove the insulation film on the earbuds before charging.

Warning: The rechargeable battery contained in this product must be properly disposed of in order to be recycled. Please do not put the battery in the fire to avoid explosion.

Recommendation: In order to maintain a good level of performance of the lithium battery in this product, it should be charged once every three months even it is not in use.

06 Product Specifications

Brand name: HAYLOU

Product model: G003

Product description: true wireless gaming earbuds

Bluetooth pairing name: Haylou G3

Bluetooth version: Bluetooth5.2

Sound modes: game/music/cinema

Low latency: 45ms*

Frequency response: 20Hz - 20,000Hz

Driver parameters: 13mm composite diaphragm dynamic driver

Earbud battery capacity: 45 mAh

Charging case battery capacity: 500 mAh

Charging time: ≤ 2 hours, The charging time of the earbuds and the charging case respectively

Box content: Charging case, Earbuds, Charging cable, User manual



CMIIT ID:2022DP7348

FCC ID:2AMQ6-G003

* The data tested by different instruments and different methods will be different.
This data is tested by the built-in Bluetooth box of AudioPrecision.

07 Troubleshoot

Problem	What to do
My G3 cannot be charged	<ul style="list-style-type: none">• Insert the USB-C (smaller end) connector firmly into the charging port at the rear of the charging case. And make sure the USB-A (larger end) connector is connected to a power source.• Make sure both ends of the charging cable are connected properly.• If your G3 has been exposed to extreme temperatures, please wait for it to return to room temperature before charging.
My G3 cannot automatically pair with my mobile device again after the Bluetooth function is restarted manually.	<ul style="list-style-type: none">• The mobile device will need to initiate the connection by itself after restarting the Bluetooth function. G3 will not initiate a connection automatically.
There is no sound from my G3	<ul style="list-style-type: none">• Increase the volume on your device.• Make sure that your G3 is connected with your mobile device, and the correct device is being used.• Try connecting to a different device.

08 Precautions

Warning

1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
2. Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C).
3. Keep the indicators away from the eyes of children and animals while using the earphones.
4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.
5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.
6. Avoid any contact with liquids.

Note

1. Please read this user manual carefully before using the product and please properly store it.
2. When using for the first time, please fully charge this product.
3. Please charge the product, in case it has not been used over two weeks.

09 Warranty Card

Warranty Period

12 months after you purchase this item.

(or you may inquire your local shopper for more details.)

Free Service

Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number	
Date of Purchasing	
User' s Name	
User' s Phone	
User' s Address	
Shop' s Name	
Shop' s Address	
Comments	

Free exchange service will not be accessed under following circumstances:

1. Damages caused by unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages caused by act of God.

Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

Manufacturer: Dongguan Liesheng Electronic Co., Ltd.

Address: Room 401-410, Building 1, No. 86 Hongtu Road, Nancheng District,
Dongguan City, Guangdong, China

