


Assembly Instructions



Console Table

Model No.
HOGA-F2358

Contact Us




We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.




We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.












⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List

1  1pc	2  1pc	3  2 pcs
4  3 pcs	5  3 pcs	6  4 pcs



Hardware List

A	B	C	D	E	F	G	H
							
Ø6X35 mm	Ø15X12 mm	Ø8X30 mm	M6X12 mm	M6X18 mm	M6X25mm	M6X58 mm	M4X64 mm
8+1 pcs	8+1 pcs	4+1 pcs	6+1 pcs	6+1 pcs	16+1 pcs	6+1 pcs	1pc


I	J	K	L	M	N	O
						
M6XØ30 mm	3.5X14 mm	4X35 mm	Ø8X40 mm	L250 mm	26X13 mm	30X20 mm
4 pcs	2+1 pcs	2+1 pcs	2 pcs	2 pcs	4 pcs	3 pcs

Installation of Cams and Pins



Read each step carefully before starting. Each step of instruction should be performed in the correct order. If these steps are not followed in sequence, assembly difficulties may occur.




Screw the pin into the hole. Set the cams correctly by aligning the head of the cams with the lock pins. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.




1



A

Ø6X35 mm
8 pcs



2



I


M6XØ30 mm
4 pcs

3




B	C
Ø15X12 mm	Ø8X30 mm
4 pcs	2 pcs

4



G	H
M6X58 mm	M4X64 mm
6 pcs	1 pc


5




F

M6X25mm
16 pcs

6




screw down




B	C	E
		
Ø15X12 mm	Ø8X30 mm	M6X18 mm
4 pcs	2 pcs	6 pcs

7




D	O
	
M6X12 mm	30X20 mm
6 pcs	3 pcs

8





J	N
	
3.5X14 mm	26X13 mm
2 pcs	2 pcs



K	L	N
		
4X35 mm	Ø8X40 mm	26X13 mm
2 pcs	2 pcs	2 pcs

10



M
L250 mm
2 pcs

Thank you for your support!

