



INSTRUCTIONS FOR MODELS


SA-2303 TOWEL RACK SA-2304 TOWEL RING SA-2305 PAPER HOLDER SA-2306 ROBE HOOK SA-2307 TOWEL BAR















- Do not over-tighten any connections or damage
- Be sure to read instructions thoroughly before beginning installation.

SAFETY TIPS

Cover your drain to prevent loss of parts.

At the selected height, mark center point of mounting locations onto wall referencing the rough in diagram.

Insert Plastic Anchors into drilled holes and screw in the anchor using a Phillips Head screwdriver, or a Drill equipped with a Phillips Driver Bit until the head is flush with the wall surface.

MAINTENANCE

•


Your new Speakman Product is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. The use of harsh chemicals and abrasives on any of the Speakman custom finish products may damage the finish and void the product warranty. Please be sure to only use approved cleaners. Please contact Speakman for any clarification of acceptable cleaners.




Additional warranty information can be found at: www.speakman.com


Align Mounting Plate over center point marked in previous step. Mounting Plate should be vertical as shown below. Mark Mounting Screw locations onto the wall surface. Remove items after marking mounting locations.


Secure Mounting Plate with the Mounting Screws provided. Verify that the Mounting Plate is aligned vertically.







ROUGH-IN DIAGRAMS






SPEAKMAN®







DIMENSIONS SUBJECT TO CHANGE WITHOUT NOTICE.