


F24CC4B

24 Inch Electric Smoothtop Cooktop

FORTÉ

Parts List



F24CC4B Parts List

No.	Description of Spare Part	SKU	QTY
1	Glass-ceramic panel	F90000605	1
2	frame	F90000606	4
3	Radiant hob	F90000607	2
4	Burner support	F90000608	12
5	Oven fixing plate	F90000609	12
6	Radiant hob	F90000610	1
7	Stove connection line	F90000611	1
8	Chassis	F90000612	1
9	Knob	F90000613	4
10	Switch waterproof ring	F90000614	4
11	Radiant hob	F90000615	1
12	Insulation strip	F90000616	1
13	Indicator light	F90000617	4
14	Heat shield	F90000618	1
15	Mount	F90000619	1
16	Energy switch	F90000620	3
17	Wiring hole sheath	F90000621	2
18	Energy switch	F90000622	1
19	Mounting frame bottom plate	F90000623	1
20	Junction Box	F90000624	1
21	power cable	F90000625	1
22	Bellows	F90000626	1
23	Bellows elbow	F90000627	1

