

5 SERIES MICROWAVE

2.2 Cubic Ft. • Countertop

F2422MV5SS

FRONT



OPEN

45° ANGLE



PRODUCT DIMENSIONS

Width	24.4 in.	61.97cm
Height	13.5 in.	34.29cm
Depth	19.6 in.	49.7cm
Turntable	16.5 in.	41.91cm
Weight	43.4 lbs.	19.6kg
Capacity	2.2 cu. ft.	62.29L
Available Colors	Stainless Steel	

ADDITIONAL SPECS

Rated Voltage	120V-60Hz
Rated Input	1700W
Rated Output	1200W
Warranty Terms	1 Year
Certification	UL Certification

FEATURES:



PUSH BUTTON OPEN

Open and close your microwave with the conventional push button.



TRIM KIT AVAILABLE

Integrate this microwave into your cabinetry with a 27" or 30" trim kit.



10 POWER LEVELS

Unrivaled flexibility with 10 unique power levels.



AUTO-COOK CONTROLS

Utilize the pre-set cooking menu to easily defrost, melt, or warm up your food.



1,200 WATT POWER

From small snacks to a whole chicken, you'll have enough power for a variety of foods.



CHILD SAFETY LOCK

Prevent accidents involving your microwave with the child lock.



SENSOR COOKING

By detecting vapor emitted from food, the microwave adjusts cooking times and power levels accordingly.



KITCHEN TIMER

Make good use of your time! A handy built-in timer will alert you when your meal is ready.

INSTALLATION GUIDE

INSTALLATION INSTRUCTIONS:

- Select a level surface which provides enough open space for the intake and/or outlet vents.
- A minimum clearance of 3.0 inches (7.5 cm) is required between the oven and all adjacent walls; one side must be open.
- Leave a minimum clearance of 12 inches (30 cm) above the oven.
- Do not remove the legs from the bottom of the microwave oven.
- Blocking the intake and/or outlet openings can damage the oven.
- Place the microwave oven as far away as possible from radios and television, as operation of the microwave oven may cause interference with the devices.
- Plug your microwave oven into a standard household outlet which matches the voltage and frequency on the rating label.

WARNING: Do not install the microwave oven over a range cooktop or other heat-producing appliances, another heat source could damage the microwave oven, voiding your warranty.

TRIM KIT LOCATIONS

- The microwave oven may be installed over a built-in oven. If installing over a built in oven, ensure there is a minimum of 3" (7.6 cm) between the top of the lower oven cutout and the microwave oven cutout floor.
- The microwave oven may also be installed in a cabinet without a built-in oven below. We recommend a minimum distance of 36" (91.4 cm) from the floor to the cutout floor.
- Ensure the surrounding cabinetry has clearance to open and close freely. Allow a clearance of at least 1 9/16" (4 cm) below the cutout floor, 3" (7.6 cm) for installation above a built-in oven, and a 2" (5.1 cm) above the cutout opening.
- Height dimension is critical: 17" (43.2 cm) minimum and 17 1/8" (43.5 cm) maximum.
- Width and depth measurements have 1/16" (2mm) tolerance.
- 3" (7.6 cm) minimum dimension is from lower oven cutout ceiling to microwave oven cutout floor.
- Trim kit frame extends 1 1/16" (2.7 cm) above and below the cutout opening.

