

REMOTE START SYSTEM

ADDING SECOND REMOTE QUICK REFERENCE

Time **Step 1**
 Disconnect the main harness from the remote start module.



This is the main remote start module, disconnecting this replaces disconnecting the B+ to allow more time to get on thru the time sensitive process.

This is step 1 & 2 in the registration procedure.

No limit

Step 2
 Cycle the ignition to start twice to get into learn mode.

Do not put foot on brake in any step, Note 5 button pushes total.

Step two needs to be completed within 30 seconds of starting.

This is step 3 in the registration procedure.

- 0
 ↓
 30
1. Push button once to ignition accessory position (on button illuminates)
 2. Push button once to ignition on position (dash lights come on)
 3. Push button once to stop ignition (off) (everything off)
 4. Push button once to ignition accessory position (on button illuminates)
 5. Push button once to ignition on position (dash lights come on)

(Stop leave ignition on)

Step 3
 With the **already programmed transmitter**, Push all three button at the same time and hold until LED show on transmitter.
 (Functions, Start, Stop), you should get a small beep confirming learn mode.



It's a little awkward, this is how I did it, one handed.

LED means car icon. (not shown in picture)

You have to release all three and than press the stop button while the car icon is still flashing.

If done properly, all icons will flash on transmitter. Improperly, only car icon will flash.

Note: you have 10 seconds to complete this step.

While car led icon is flashing press stop button once.

0
 ↓
 20

Step 4
 With the new transmitter (not programmed) repeat the same exact procedure as step #3.

The procedure must start within 20 seconds of concluding step 3.

Note this step 5 of registration procedure

Step 5
 Up to three transmitter can be programmed. If programming a third transmitter, repeat Step 3.

Step 6
 Conclude programming sequence.

Press and hold Stop button until it beeps. This can be done on any of the three programmed transmitters.

If #1 transmitter (original) is hard programmed, you will hear long beep followed by short beep.
 If #2 transmitter (new) is hard programmed, you will hear long beep followed by two short beeps
 If #3 transmitter (optional) is hard programmed, you will hear long beep followed by three short beeps.

If successful, exit vehicle with all transmitters and key, ensure all doors are closed and test both transmitters.

rev: 4/24/2012