OPERATION GUIDE



01

Note: If the hearing aid is silent or the sound

becomes low due to the blockage of the

sound outlet, please clean the sound outlet.

2. Why is there a howling (sharp sound)?

the normal working of hearing aids. The

Howling (sharp sound) is a manifestation of

Before wearing



Please use a cotton swab to clean the ear canal before wearing. If the cerumen is too much, it will block the sound outlet of the product and cause no sound.

How to wear



1. Choose earplugs that fit your ear canal size.



3. Turn on the hearing aid after wearing it

2. Install the selected earplugs and the machine



4. Adjust the volume to suit you

canal and wear them correctly to fit your ears as much as possible. If you don't wear it properly, there will be echoes (whistles/sounds).

Note: Be sure to choose earplugs that fit your ear

Note: After wearing, you can turn on the hearing aid to adjust the volume and program!!!

Problems encountered in wearing

1. There is no sound when wearing? If there is no sound:

①Check whether the volume program is adjusted to suit your hearing

2 Check whether the hearing aid has elec-

3Whether there is no episode in the ear canal, and the earwax is blocking the sound of the hearing aid.

04

Charging



Charging compartment Flashing green = charging Steady green light = charging is complete Hearing aid Blue light always on = charging Blue light off = charging is complete



Green light always on = charging Green light off = charging is

Charging

- 1. When charging the hearing aid, it can be charged through the power adapter or through the USB interface 2. Hearing aid charging: first turn off the
- power of the hearing aid, and then charge it. The first charge should ensure sufficient charging time (not affected by the indicator light), and a charging time of 5-6 hours should be guaranteed
- 3. If the hearing aid is not used for a long time, the battery self-discharge will cause the battery to be seriously insufficient. It should be charged, and the charging time should reach 6 hours. Even if the charging indicator shows that the charging is complete, the charging should not be stopped (quarantee to reach 6 hours)

Clean

If the hearing aid is silent or the sound becomes low due to the blockage of the sound outlet, please clean the earplugs and the sound outlet as shown in the figure



21-day wear chart

THE JOURNEY TO LISTENING

Unlike vision correction, which simply

wears glasses, hearing correction is a

rather detailed process. Once you start

your hearing correction journey, you will

experience countless "new sounds", and

your brain needs to adapt for a period of

time. In just a few weeks, you will be

shocked by the sound that you have

If you have any questions, we will serve

never experienced before.

you wholeheartedly.

10

THE FIRST WEEK

Some sounds may be too noisy when wearing a hearing aid for the first time, such as the buzzing of the refrigerator, the wrinkling of paper, or the sound of your footsteps. This is normal, and your brain is relearning how to prioritize these sounds that you don't hear very often. Sometimes you may not like the noise, but please don't give up wearing. Please don't give up wearing them!

aid for 30 minutes a day, and the

4. During use, the hearing aid volume

becomes low or when the hearing aid is not

charged (this will better protect the hearing

in use, the power should be turned off and

aid battery). This is very important! Other-

Will reduce the battery capacity and affect

6. When using AC power to charge, if the

charging is over, unplug the power in time

11

wise it will cause excessive discharge

5. The hazards of excessive battery

the battery life to varying degrees

discharge

THE THIRD WEEK

After a few weeks, you will feel more energetic because you no longer need to spend a lot of energy to listen what others say. The sound will become clearer and clearer, and you will once again enjoy the sounds that surround in your life, such as the melodious singing of birds in the backyard, the cheerful laughter of children, and the rustling of leaves in the wind.

12

Participate

ve a meal in a restaurant with

THE SECOND WEEK

The more you wear the hearing aid, the more you can adapt to the sound environment. You even can ask people around you not to speak loudly to you anymore, because you can easily communicate with people.

15

16

Solution: The product is equipped with earplugs of different sizes, please choose the earplugs that fit your ear canal

05

Turn ON/OFF

Turn the power switch to OFF to turn down.



02

After wearing, turn it on to prevent howl-



Volume control

ing/acoustic echo during wearing.



06

lower the volume

Increase the volume

Move the scroll wheel upward by hand to increase the volume, and downward to decrease the volume. There are 4 levels of volume, 4 levels are the loudest.

03

Bluetooth connection



1) Short press play/pause/answer call 2 Long press to switch Bluetooth mode

③ Double click to connect to Bluetooth with one ear 4 Triple click to switch

M key function

hearing aid mode ⑤ Four clicks to manually TWS group pairing



07