
YAY! YOUR DAY JUST GOT SO FUN

BOUNCEE HOUSE MANUAL



MEET YOUR BOUNCEE HOUSE

a.ka. your #bounceebabes new b.f.f.



WHAT'S INCLUDED:

o One Bouncee House

o Carrying bag

o Blower

o Stakes

o Repair kit

BEFORE YOU SET UP

Core memory makers:
Please read all instructions before
assembling this bounce house,
and keep instructions for future
use.

- 1—Find play area and get organized. You'll need a flat, soft, open space with enough room for your bounce house, plus an additional 2 meters on each side (18 sq ft total) that is free of hazards.
- 2—Locate the fabric blower tube. Attach tube to blower with elastic closure and securely tie in place. Once secure, you may plug in your blower using GFCI protection.
- 3—Turn on your blower & inflate! Product must be fully inflated and anchored before play begins.
- 4—Enjoy the view of your littles having fun. It's truly the best.

- o Anchoring Instructions: All six stakes are to be driven straight down until the top is below ground level. Do not drive at an angle. For best hold, drive stakes into hard, dry soil. In loose or wet soil, or both, holding strength will be reduced.
- o For indoor use, use at least 125 lbs of anchoring equipment equally distributed.
- o Do not use in windy conditions.
- o Only for use with provided blower or with an equivalent 450W blower.
- o A GFCI must be used. Do not use an extension cord. Keep blower/power cord away from water.
- o Do not install house over a hard surface, or a fall can result in serious injury.

WHILE YOU PLAY

- o Parent supervision required. Please observe from the front of the bounce house where all parts of the play area can be seen.
- o Keep the entrance free from obstruction at all times.
- o Restrict use to a maximum of 2 users at one time and maximum weight 160 lbs.
- o Do not attach items to the house that are not designed for use with the house, such as, but not limited to: jump ropes, leashes, cables, etc., as they have the potential to cause a strangulation hazard.

KEEP YOUR #BOUNCEEBABES SAFE:

- o No climbing or hanging on the containing walls.
- o Prevent inappropriate activities (i.e. no wrestling, somersaults and rough play, etc.).
- o Avoid and remove all loose clothing, hard, sharp, or dangerous objects, such as, but not limited to: jewelry, helmets, etc.
- o Do not eat food and/or drink or chew gum to prevent choking.
- o Keep pets off bounce house.

Note: This bounce house requires continuous air flow to stay inflated. Air leakage is normal to prevent overinflation. It is not recommended to seal or patch seams.

The included repair kit is for fabric tears only.

AFTER YOU'RE DONE

- 1—In order to disassemble safely, please make sure no users are on or near the bounce house.
- 2—Once the users are clear, turn off the blower, and maintain a safe distance until fully deflated.
- 3—When deflated, you can unplug the blower and remove blower tube from the blower.
- 4—You can now fold and roll the bounce house, to expedite getting the last bits of air out, or simply give it more time to deflate.
- 5—Now you're ready to fold and store your bouncer!

MAINTANENCE & STORAGE:

- o If you need to clean your bounce house, please spot clean only. Use any non-flammable, non-toxic cleaning or sanitizing solutions. We recommend testing cleaner in an inconspicuous place in case of reactions or staining.
- o Watch for excessive wear or deterioration. Discontinue use if found.
- o Before storing your bounce house, please ensure it is free of dust, dirt, debris and moisture. This will prevent mold and damage during storage.



EXTRA INFORMATION

WARNINGS & CAUTIONS:

WARNING: Please read and follow all safety information before use. Failure to follow the installation and operating instructions present a risk of serious injury or death.

WARNING: Follow Anchoring Instructions.
User must read and follow anchoring instructions to ensure the proper: number of anchors used, soil conditions, and stake installation.

ELECTROCUTION RISK: Keep all electrical lines, radios, speakers and other electrical devices away from the Constant Air Inflatable. Do not place the bounce house near or under overhead electrical lines.

CAUTION: This is an electrically operated blower/product, and must be operated by adults only. Do not use extension cords. Please take precautions to avoid injury or electrocution when handling. Do not allow the cord to run under the house.

CAUTION: Due to the nature of product, please be aware that falls and bumps are possible. Head and other serious injuries can result from play.

BLOWER SAFETY & MAINTANENCE:

o **CAUTION**: Electrically operated product. For adult use only. Keep away from Children.

o **Electrocution Hazard**: Do not use extension cord with this product.

o **DANGER**: Place blowers and electrical cords at least 1.3 m (4.3 ft) from the back side of the bounce house. Do not allow electrical cords to pass under the bounce house.

o Our blower tubes are designed to enable the positioning away from users. Do not place blower in a fall zone.

o Do not use with extension cords. Use only supplied GFCI protected power cord.

o Please ensure that the intake of the blower is not affected by any foreign debris in order to ensure proper air volume.



RULES FOR USE & PLAY

Please make sure that you and your child understand all of the rules before setup or play.



Maximum number of jumpers



Total weight limit



Total height of jumper



Age range



Adult supervision required



Feet first sliding only



Drive stakes straight into ground until level with ground



Use proper anchoring equipment when used indoors



No wrestling, rough play, or flipping



No glasses, jewelry, sharp or dangerous objects.



No climbing on net



No pets allowed



Do not use in windy conditions



Electrocution risk. Blower and cord for adult use only.



No food, drink or gum.



HAVE FUN!

RULES OF OPERATION

- 1. Adult supervision required at all times.
- 2. Age range 2-8
- 3. Total weight limit-160 lbs
- 4. Total number of children-2
- 5. No head-first sliding. Always slide feet-first.
- 6. No shoes, glasses, jewelry or sharp objects allowed.
- 7. Do not eat, drink or chew gum on bounce house
- 8. Do not operate in rainy or windy conditions.
- Your play area should be a flat, soft, open space with enough room for your bounce house, plus an additional 2 meters on each side (18 sq ft total) that is free of hazards.
- 10. All six stakes are to be driven straight down until the top is below ground level. Do not drive at an angle. For best hold, drive stakes into hard, dry soil. In loose or wet soil, or both, holding strength will be reduced.
- 11. Place blowers and electrical cords away from the backside of the house.
- 12. Any restrictions relating to operating surfaces and anchors.
- 13. HAVE SO MUCH FUN!

WARNINGS & CAUTIONS

WARNING: Failure to follow the installation and operating instructions present a risk of serious injury or death.

WARNING: Follow Anchoring Instructions.

User must read and follow anchoring instructions to ensure the proper: number of anchors used soil conditions, and stake installation

ELECTROCUTION RISK: Keep all electrical lines, radios, speakers and other electrical devices away from the Constant Air Inflatable. Do not place the bounce house near or under overhead electrical lines.

CAUTION: This is an electrically operated blower/product, and must be operated by adults only. Do not use extension cords. Please take precautions to avoid injury or electrocution when handling. Do not allow the cord to run under the house.

CAUTION: Due to the nature of product, please be aware that falls and bumps are possible. Head and other serious injuries can result from play.

*Note: This bounce house requires continuous air flow to stay inflated. Air leakage is normal to prevent overinflation. It is not recommended to seal or patch seams. The included repair kit is for fabric tears only.



WE LOVE HEARING FROM YOU! IF YOU HAVE QUESTIONS OR CONCERNS, PLEASE REACH OUT:

www.bounceeco.com hello@bounceeco.com

FOLLOW & TAG US!

@bounceeco #bounceebabes

Bancee