

**Notes:**

The battery error displays if there is a difference in battery voltage between the two batteries greater than 1.5v (Setting \$I)
 Battery 1 is the top (nose) position

