



Instructions

Remove, inspect and clean the three Black connectors going between the motor and electronics. Ensure they are all making good connection.

Did this fix it?

Contact Dive Xtras

Happy Diving

Switch any two black wires. This will change motor direction.

The correct running of your scooter motor is reliant on the three black connectors in your scooters tail working correctly. A poor connection here can result in various motor issues.

