


USW - Sentry Sign Holder Instruction Sheet




STEP 1

ALIGN ADAPTER AS SHOWN WITH KEY HOLE ON TOP.



STEP 2

ALIGN STEM TO SIGN FRAME AND ADAPTER. SECURE PARTS USING PHILLIPS HEAD BOLT, LOCK WASHER AND FLAT WASHER.



STEP 3

TAKE ASSEMBLED FRAME AND ALIGN LONG LEGS OF ADAPTER TO TOP OF STANCHION AS SHOWN IN "I" AND "J". TAKE THUMBS AND PUSH OUTWARD TO CAPTURE SHORTER LEGS ON OUTSIDE OF STANCHION AS SHOWN IN "K". ONCE SIGN FRAME IS IN PLACE PUSH DOWN TO SECURE.



STEP 4

REMOVE ANY PROTECTIVE FILM FROM PLEXIGLASS. INSERT SIGNAGE BETWEEN THE (2) PIECES OF PLEXIGLASS AND INSERT INTO THE TOP OF FRAME AS SHOWN.

Thank You for purchasing the Sentry Sign Holder.

For customer service please call us toll-free at 877-201-9748

or email usw.sales@escaladesports.com.

For additional crowd control products please visit us at www.usweight.com