

⚠ WARNING!


Keep away from fire
Use only with adult supervision
Assembly by adults only

Size: W46in x H56in

Material:

White Beech Wood


PARTS:



ASSEMBLE INSTRUCTION:


STEP 01

Insert part D, aligning for screw to insert on side




STEP 02

Loosely screw in part C, connecting to part D
Do not fully tighten all the screw yet.




STEP 03

Repeat steps 1-2 for every rung on one side of Play Gym




STEP 04

Repeat steps 1-3 on opposing side of Play Gym




STEP 05

Push the sides of the Play Gym together making sure all the rungs are flush to the flat surface. Finally, tighten all screws.



STEP 06



GATHRE

2575 W 400 N, Suite 100
London, UT 84042

PH: (888)-(830)-6054