

## USING THE LION PROWLER

- To check the charge of the Prowler, press the power button for one second. Lights will display on the left of the power button.
  Four lights means the unit is fully charged.
- To charge the Prowler, use the USB cord provided. Plug the USB end of the cord into a power source and the other end of the cord into the Prowler, near the power button (lift the rubber flap).

## **USB CHARGING**

- Using the cable provided, connect the device (ie. phone, tablet, etc.) into the output on the end of the Prowler, near the power button (lift the rubber flap).
- Press the power button for 1 second to turn on power & begin charging device.
- When finished charging, turn the Lion Prowler off.

Get more information at www.lionenergy.com

## WIRELESS PHONE CHARGING

- Press the power button on the Prowler twice. A red light indicator on the far-left side of the power button will turn on.
- Place the smart phone directly on the top of the Prowler; a green light will come on and it will start charging. Note: Your phone case may prevent wireless charging.
- To turn off wireless charging, press the power button twice.

## **FLASHLIGHT SETTINGS**

- To turn the flashlight on, press and hold the flashlight icon (next to the power button) for one second. This will turn the flashlight on to Solid mode.
- To turn the flashlight to SOS mode, press & hold the flashlight icon for 3 seconds.
- To turn the Lamp on, press the flashlight icon twice.



