



BATTERY CHARGER

MGI Ai Series and Zip Series 24 Volt Lithium-Ion Battery

Model: LC-2323

User Manual
and Important Safety Information

VERSION 1.5

IMPORTANT

- The battery is designed for indoor charging only. Please ensure it is used on an uncarpeted, non-flammable hard floor in a well ventilated area.
- Do not attempt to use the charger if it has been dropped or damaged.
- Never attempt to charge a damaged, water-damaged, frozen or non-rechargeable battery.
- Do not smoke, use an open flame or create sparks near your battery and charger during charging.
- Do not operate the charger if the cord or plug is damaged.
- Do not attempt to open or repair the battery or charger. Doing so may cause injury and will void warranty.
- Ensure the battery is fully charged after each use no matter how many holes are played. The lithium battery is designed to last a full round of golf.
- Never attempt to fully discharge your battery. If your Ai or Zip Series cuts out repeatedly, please take your model, battery and charger to your nearest MGI service agent.

Battery Storage

- Lithium batteries should not be stored for long periods of time, either depleted or fully charged. Ideally the battery should be at 40-50% capacity, stored in a clean dry environment on a hard, non-flammable surface, between 15°C (60°F) to 25°C (80°F). As lithium batteries slowly discharge over time, it is recommended that the battery be power cycled every 6 months, if left unused, and re-stored as above.

Operating Instructions


- Prior to first use and after every use, charge the battery.
- Do NOT charge your MGI lithium battery for more than 10 hours. Once the battery is fully charged, unplug from charger or disconnect power supply.
- Prior to first use and after every use, charge the battery.
- Please ensure that when connecting your battery charger, the connectors line up red-to-red/black-to-black.

- Only the charger supplied with your Ai/Zip Series is to be used to charge the battery. Using an incorrect charger, or using the Ai charger to charge a Zip battery will cause damage to both the charger and battery and will void the respective warranties.
- Plug the charger directly into a wall power point. Do not use a multi-outlet power board to charge the battery.
- Always place the battery after use, no matter how short the period of use. Your battery will charge best, lying flat, in a warm and air ventilated location.
- Charge your battery in ambient temperatures between 5°C (30° F) and 30° C (86°F).
- To minimise drain on the battery during play, avoid taking your Ai/Zip Series into thick rough where possible.
- The Ai/Zip Series is designed to carry a maximum load of 20kg (approx 45 lbs) - do not use the Ai/Zip Series as an aid to traverse up and down hills as this will drain the battery and may cause overload of the drive system.
- Lithium batteries are a dangerous good and cannot be transported via air travel - please contact you airline prior to travel.
- Be very careful not to drop your battery. The battery casing and the battery's subsequent life will be severely compromised Any damage/impact may compromise battery performance, longevity and safety functionality- replace battery immediately.
- Your lithium battery leads, casing and connections should be regularly inspected for damage and wear.
- If your leads or connections need repair or replacement, please contact your local MGI repair centre for assistance immediately. Do not use the charger for charging if the connections are damaged
- Under no circumstances should a lithium battery that has been dropped, damaged or immersed in water be connected to an Ai/Zip Series or charger. By doing so, you may create a fire hazard or risk the battery catching fire. Please safely dispose of your battery immediately.
- Please ensure the chassis battery housing and connectors are free from debris before connecting the battery.
- The battery is a sealed battery. If you are intending to take your Ai/Zip Series Model and battery on air travel, we advise that you make contact with your airline prior to travel.

Charging Process

LED Indicator

- The charging indicator will show the different states of the battery during the charging process.



- The Green LED illuminates solid to indicate the charger is powered on.
- The Red LED illuminates solid to indicate when charging.
- The LED will turn solid Green when the battery is fully charged.

- If the Green or Red LED indicator flashes constantly, this indicates that the charging process has failed, there may be a problem with your charger or battery. In this situation you should contact the MGI service centre.
- If the LED indicator light does not turn Green when the power is connected, there may be a problem with your charger. In this situation you should also contact the MGI service centre.

Dangers Around Water-Damage

Should your Lithium battery or battery charger come into contact with water or other conductive liquid, MGI strongly advises the ceasing of usage battery, and or charger, and to responsibly dispose of the effected part.

Please visit these links for further information:

Battery care and maintenance

mgigolf.com/pages/caring-and-maintaining-lithium-batteries

Battery water-damage

mgigolf.com/blogs/news/water-damaged-batteries-buggies

PLEASE NOTE: The ongoing use of a lithium battery compromised by exposure to water carries a heightened risk of thermal runaway, overheating, combustion, or explosion.

Warranty Information

Your MGI Ai/Zip Series model has a 36 month manufacturer warranty from the date of purchase against faulty material or workmanship which includes the battery and charger.

***Chargers purchased separately come with a 12-month manufacturer warranty from date of purchase.**

This warranty is void if; the charger has been tampered with, used in a unsuitable environment, electrically overloaded, water-damaged or any other condition stipulated in this user manual.

IMPORTANT: Register your Ai/Zip Series Model online to validate your warranty. Visit mgigolf.com to register.

Customer Support

For customer support, please contact MGI directly for immediate and professional advice.

mgigolf.com

MGI AUSTRALIA

Service Email: customerservice@mgigolf.com

Live Chat: visit mgigolf.com

Toll Free within Australia: 1300 644 523 (excludes mobiles)

Western Australia/ Internal phone +61 3 8872 6700

Local Service Centres: visit mgigolf.com

Sales Email: sales@mgigolf.com

MGI USA

Sales Email: salesusa@mgigolf.com

Service Email: serviceusa@mgigolf.com

Live Chat: visit us.mgigolf.com

Telephone: 1800 617 2990

MGI GLOBAL

Sales Email: globalsales@mgigolf.com

Service Email: globalservice@mgigolf.com

Live Chat: visit mgigolf.com



mgigolf.com

MGI AUSTRALIA

Service Email: customerservice@mgigolf.com

Live Chat: visit mgigolf.com

Toll Free within Australia: 1300 644 523 (excludes mobiles)
Western Australia/ Internal phone +61 3 8872 6700

Local Service Centres: visit mgigolf.com
to locate you local service centre.

MGI USA

Service Email: serviceusa@mgigolf.com

Live Chat: visit mgigolf.com

Telephone: 1800 617 2990

MGI CANADA

Service Email: servicecanada@mgigolf.com

Live Chat: visit mgigolf.com

Telephone: 1800 617 2990

MGI GLOBAL

Sales Email: globalsales@mgigolf.com

Service Email: globalservice@mgigolf.com

Live Chat: visit mgigolf.com

Follow us on



*Absolute attention has been taken to ensure this manual is correct at time of printing. Specifications, images and statistics may change at any time.
Visit www.mgigolf.com for the most current model information. Version 1.5. 02/24*