




# BLADE

## OPERATING INSTRUCTIONS

P.O Box 68323, Bryanston 2021  
200 Cussonia Park, 3 Ridge Road,  
Laser Park, Honeydew, South Africa  
Tel: (011) 794-6311 • Fax: (011) 794-6233



## HELPFUL HINTS


1. Always make sure TENT is dry when stored - away from RATS and MICE.
2. Do not wash TENT with detergent. ONLY wipe with CLEAN CLOTH.




# BLADE

## OPERATING INSTRUCTIONS - TO OPEN


P.O. Box 68323, Bryanston 2021  
200 Cussonia Park, 3 Ridge Road,  
Laser Park, Honeydew, South Africa.  
Tel: (011) 794-6311 • Fax: (011) 794-6233




Blade in closed position




Loosen securing latch by  
Pressing on latch lock.




Guide latch lock through  
centre hole.




Take Hold of handles and lift in order  
to open tent.



Tent in open position.



Remove Retractable ladder in bag  
from tent.



Remove bag from retractable ladder.







# BLADE

P.O. Box 68323, Bryanston 2021  
200 Cussonia Park, 3 Ridge Road,  
Laser Park, Honeydew, South Africa.  
Tel: (011) 794-6311 • Fax: (011) 794-6233


## OPERATING INSTRUCTIONS




Place ladder into ladder locking plate.




Adjust ladder foot piece to required height by pulling on the rope. Make sure pins are located before climbing up.




Pull on ladder lock straps to extend retractable ladder.



Insert canopy rod into stainless steel insert in tent.



Thread the hook end of canopy rod through eyelet in tent canopy.




JOB WELL DONE




## OPERATING INSTRUCTIONS - TO CLOSE


P.O. Box 68323, Bryanston 2021  
200 Cussonia Park, 3 Ridge Road,  
Laser Park, Honeydew, South Africa.  
Tel: (011) 794-6311 • Fax: (011) 794-6233




Clip the elastic cords together again in help with closing of the tent.




There is an elastic cord that helps pull the sides of the tent in to gain easy access to this cord a pull toggle has been attach to it.




Pull on the toggle and move the strap up so as it's in the middle of the fabric in order to pull fabric inwards.




Remove canopy rods.



Remove retractable ladder.



Slide retractable ladder back into the closed position by pulling on ladder locks. Take care not to jam fingers when sliding.



Slide retractable ladder bag over ladder and stow in tent.







# BLADE

## OPERATING INSTRUCTIONS - TO CLOSE


P.O. Box 68323, Bryanston 2021  
200 Cussonia Park, 3 Ridge Road,  
Laser Park, Honeydew, South Africa.  
Tel: (011) 794-6311 • Fax: (011) 794-6233




Pull down on pull strap in order to close tent.




Leaving a window open with the gauze closed helps release trapped air from tent.



Latch lid of tent closed .



Latch lock may require a little guiding in to go through centre hole.




ON THE ROAD AGAIN!! - ENJOY THE RIDE!!




## INSTALLATION INSTRUCTIONS

P.O. Box 68323, Bryanston 2021  
14 Susan Str. Strydompark. Randburg  
South Africa  
Tel: (011) 792-1731 Fax (011) 791-0727




Slide fitting kit plates into tent rails and secure.



### Internal Light.

If the tent is fitted with an internal light the extension cord should be connected to the tent first in order to prevent a short circuit. If a short circuit has occurred replace 15 Amp inline fuse with a new one.

PLAN VIEW  
DART BASE  
RAIL CENTRES



Eezi-Awn reserves the right to modify their equipment at their own discretion.