








SKU	Name	Description	Photo
BRK-430000 BRK-430001 BRK-430012 BRK-430013 BRK-431000	ONBOARD TOUCHSCREEN DISPLAY / CONTROL	Included color touch-screen. Commissioning wizard. Filter wizard. Filter / error messages, also via LED. Built in 4-way speed switch.	
BRK-540262	BRINK 4-POSITION WIRED SWITCH + LED	BRINK 4-position switch for adjusting flow rates at a remote location. Equipped with a filter indicator light.	
BRK-532174	BRINK BOOST SWITCH (momentary)	The BOOST SWITCH allows a manual 30 minute boosting of the system. Install in bathrooms and kitchen as desired. Up to 5 / unit.	
BRK-532126	BRINK CO2 SENSOR	BRINK CO2 SENSOR allows for demand controlled ventilation. CO2 sensor will ramp flow according to need. Up to 4 / unit can be used.	
BRK-310657	BRINK RH SENSOR	RH SENSOR boosts the system for 30 minutes in response to increased moisture in ventilation air. Can use instead of boost switch. Install in return or master bathroom.	
BRK-532743	BRINK TOUCH CONTROL	The TOUCH CONTROL allows you to control the unit at a remote location via compact touch screen display.	
BRK-532700	BRINK FLAIR PLUS MODULE	The PLUS PCB board allows you to connect your BRINK Flair to the Internet, a Building Automation System (BAS), and the BRINK Home app.	

Questions? Contact [info@475.supply](mailto:info@475.supply)