

Diameter 2.0 cm / 0.78 in



Press ON/OF and hold for two seconds



ON/OFF changes the modes of vibration

- Powerful motor
 Press ON/OFF (b) and hold for two seconds.
 (c) ON/OFF changes the modes of vibration
- Ein leistungsfahiger Motor
 Für die Entsicherung drücke ON/OFF (b)
 und halte den Knopf für zwei Sekunden
 lang gedrückt.
 - (b) ON /OFF Ändern der Vibrationsmodi
- Moteur puissant
 Appuyez sur ON/OFF (b) et maintenez
 la touche enfoncée pendant deux secondes.
 (b) ON / OFF change les modes de vibration
- Motor potente
 Pulse ON/OFF (b) y mantenga pulsado durante
 2 segundos.
 - (b) ON/OFF cambio de modos de vibración
- RU Сильный мотор Нажмите ON/OFF (ф) и удерживайте 2 секунды. для включения.
 - (b) Кнопка ON/OFF переключение режимов вибрации

Remote control of Gring XL

Gplug XS can be controlled remotely by a no-cord controller – the Gring XL (sold separately). The controller fits a finger perfectly enabling an easy switch to a different mode while you enjoy the Gplug XS.



ON/ increasing the vibration



Modes of vibration



Decreasing the vibration / OFF

CHARGING

Connect the charger to the points of charging at the bottom of the toy. The USB-end is connected to the USB port of your computer of adaptor. When charging a light indicator starts blinking. As soon as the toy is full charged the light stops blinking. The buttons will not work when charging meaning you can't use the toy.

- When the battery is low Gplug XS will switch modes automatically to switch off.
- Charging time is around 1.5 hours. After charged fully the toy runs about 40minutes at max speed.

3-YEAR WARRANTY