




# Gring XL



EN

Powerful motor

Press  $\oplus$  and hold for two seconds to switch on.

$\oplus$  increase the vibration

$\circlearrowright$  modes of vibration

$\ominus$  decrease the vibration /OFF

DE

Leistungsstarker Motor

Für die Entsicherung drücke  $\oplus$  und halte den Knopf für zwei Sekunden lang gedrückt.

$\oplus$  verstärken der vibration

$\circlearrowright$  schwingungsarten

$\ominus$  vibration verringern / OFF

FR

Moteur puissant

Appuyez sur  $\oplus$  et maintenez la touche enfoncée pendant deux secondes.

$\oplus$  augmentation de la force de vibration

$\circlearrowright$  modes de vibration

$\ominus$  réduction de la force de vibration / OFF

ES

Potente motor

Pulse  $\oplus$  y mantenga pulsado durante 2 segundos.

$\oplus$  aumentar la intensidad de la vibración

$\circlearrowright$  modos de vibración

$\ominus$  reducir la intensidad de la vibración / OFF

RU

Сильный мотор

Нажмите  $\oplus$  и удерживайте 2 секунды для включения.

$\oplus$  увеличение силы вибрации

$\circlearrowright$  режимы вибрации

$\ominus$  уменьшение силы вибрации /OFF

## Using GringXL as vibrator

GringXL has the «Travel Lock» protection from accidental activation. To turn on the GringXL press the  $\oplus$  button and hold for 2 seconds.


To switch the vibration mode, click on the middle button. GringXL has 6 vibration modes.

### SWITCHING OFF

To turn off the GringXL, press the  $\ominus$  button until it turns off.

## Gring as a remote control for other Gvibe toys


Please make sure that your Gvibe toy is compatible with the GringXL. The GringXL and the Gvibe toys connect automatically right after turning on. This is how you can manage the toys by Gvibe now:



● ON/increasing the vibration



● Modes of vibration



● Decreasing the vibration / OFF

## CHARGING

Connect the charger to the points of charging at the bottom of the toy. The USB-end is connected to the USB port of your computer or adaptor. When charging a light indicator starts blinking. As soon as the toy is full charged the light stops blinking. The buttons will not work when charging meaning you can't use the toy.

- When the battery is low Gring XL will switch modes automatically to switch off.
- Charging time is around 1.5 hours. After charged fully the toy runs about 40minutes at max speed.

## 3-YEAR WARRANTY