

Hot Melting Glue Gun User Guide

for Models:

JQ-010 JQ-050 JQ-100A



ORIGINAL INSTRUCTIONS

USED SYMBOLS



READ THESE INSTRUCTIONS



CLASS II CONSTRUCTED



DO NOT DISPOSE OF ELECTRIC TOOLS, ACCESSORIES AND PACKAGING TOGETHER WITH HOUSEHOLD WASTE MATERIAL

WORKING SAFELY WITH THIS UNIT IS POSSIBLE ONLY WHEN THE OPERATING AND SAFETY INFORMATION ARE READ COMPLETELY AND THE INSTRUCTIONS CONTAINED THEREIN ARE STRICTLY FOLLOWED.

- If the cable is damaged or cut through while working, do not touch the cable but immediately pull the mains plug. Never use the unit with a damaged cable.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- For indoor use only.
- Connect units that are used outdoors by means of a fault current protection switch (FI) with a maximum triggering current of 30 mA. Use only an extension cable that is approved for outdoor use.
- Always direct the cable to the rear away from the unit.
- For pauses in the work of more than 30 minutes, pull the mains plug.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Manufacturer is able to ensure flawless functioning of the unit only if the original accessories intended for it are used.
- Do not work materials containing asbestos (asbestos is considered carcinogenic).

- Take protective measures when during work dust can develop that is harmful to one's health, combustible or explosive (some dust mask are considered carcinogenic); wear a dust mask and work with the dust / chip extraction when connectable
- Do not change nozzles while glue gun is in "on" position, plugged in, or warm to the touch. Before changing nozzles, make sure glue gun is cool to the touch, unplugged, and the switch is in the "off" position.

ENVIRONMENT

DISPOSAL

The unit, accessories and packaging should be sorted for environment-friendly recycling.

ONLY FOR EUROPEAN COUNTRIES



Do not dispose of power tools into household waste! According to the European Guideline 2012/19/EC for Waste Electrical and Electronic Equipment and its implementation into national right, power tools that are no longer usable must be collected separately and disposed of in an environmentally correct manner.

SPECIFICATIONS

GENERAL SPECIFICATIONS

Description: **Glue Gun:**

Model number	JQ-010	JQ-050	JQ-100A
Power	8-10W	50W	100W
Temp	180°C	180°C	200°C
Glue syick	7mm	7mm	11mm

EXTENSION CORDS

Use completely unrolled and safe extension cords with a capacity of at least 5 Amps.

Model: JQ-010

Micro USB type C port
Mobile phone charger is available
Runtime one hour with a full charge

Models : JQ-010 JQ-050

- Allow glue gun to reach operating temperatures before using (+/- 5mins). Insert the glue stick . Press the feed trigger.

Model : JQ-0100A

- Once the cord is detached, the glue gun remains operable for 5mins, before it needs o heat up. NOTE: For your first use, you may need to load up to two full glue sticks before glue begins to flow.
- Squeeze trigger to apply glue onto desired surface.
- Apply parts together.
- Allow glue to cool before handling object or surface.

TIP: Manufacturer also supplies glitter and colour sticks for decorative purposes. These sticks have been specially developed for creative projects and low temperature (105 °C). The colour sticks can also be used for sealing decorations. To be able to quickly change colours, it is recommended to cut the sticks into 3cm pieces before inserting into the Glue Gun.

White Transparent $\Phi 7 \times 100\text{mm}$
Black Transparent $\Phi 7 \times 100\text{mm}$
Mucosity70% Semi Transparent $\Phi 11 \times 150\text{mm}$
Mucosity 80% Transparent $\Phi 11 \times 150\text{mm}$

DRIP-CONTROL FUNCTION

When heated up, the glue gun has a drip-control function. This prevents the glue from dripping when the glue gun is at operating temperature.

NOTES: During heating-up the glue gun may release a few drops of glue. Do not use glitter or colour sticks at high temperature. The drip-control function will not work properly.

CHANGE GLUE STICKS

Do not attempt to remove the unused portion of the glue stick from your glue gun. If you need to switch glue stick formulas, empty the melting chamber by squeezing the trigger and insert new formula.

STAND / KICK STAND

When glue gun is hot, do not lay on its side. Always use stand.

- Push stand into "down" position when temporarily not in use.
- When re-suing or storing, push stand back into "up" position.

MAINTENANCE

CLEANING

BEFORE ANY WORK ON THE UNIT ITSELF, PULL THE MAINS PLUG.

Always keep the unit clean so that it functions properly and accurately.

SERVICE AND WARRANTY

This product is guaranteed in accordance with statutory/country specific regulations; damage due to normal wear and tear, overload or improper handling will be excluded from the guarantee. If the unit should fail despite the care take in manufacturing and testing, send it undismantled together with proof of purchase to your dealer.

SHENZHEN ATTEN TECHNOLOGY CO.,LTD.

Add: Floor 8, Building 2, Senyang High-tech park, 7 West Road High-tech Park, Guangming New district, Shenzhen 518132, china

Tel: 86-755-8602 1373 Fax: 86-755-8602 1365

Web: www.atten.com

Facebook: <https://www.facebook.com/attencn/>

E-mail: sales@atten.com.cn