

Bank	Preset	CC# Value 1	CC# Value 2	
1	1	1	1	Press
	2	2	2	Release
	3	3	3	Toggle On
	4	4	4	Toggle Off
	5	5	5	Long Press
	6	6	6	Long Release
	7		7	
2	1		8	
	2		9	
	3		10	
	4		11	
	5		12	
	6		13	
	7		14	
3	1		15	
	2		16	
	3		17	
	4		18	
	5		19	
	6		20	
	7		21	
4	1		22	
	2		23	
	3		24	
	4		25	
	5		26	
	6		27	
	7		28	
5	1		29	
	2		30	
	3		31	
	4		32	
	5		33	
	6		34	
	7		35	
6	1		36	
	2		37	
	3		38	
	4		39	
	5		40	
	6		41	
	7		42	

7	1	43		
	2	44		
	3	45		
	4	46		
	5	47		
	6	48		
	7	49		
8	1	50		
	2	51		
	3	52		
	4	53		
	5	54		
	6	55		
	7	56		
9	1	57		
	2	58		
	3	59		
	4	60		
	5	61		
	6	62		
	7	63		
10	1	64		
	2	65		
	3	66		
	4	67		
	5	68		
	6	69		
	7	70		
11	1	71		
	2	72		
	3	73		
	4	74		
	5	75		
	6	76		
	7	77		
12	1	78		
	2	79		
	3	80		
	4	81		
	5	82		
	6	83		
	7	84		
	1	85		

13	2	86		
	3	87		
	4	88		
	5	89		
	6	90		
	7	91		
	14	1	92	
2		93		
3		94		
4		95		
5		96		
6		97		
7		98		
15	1	99		
	2	100		
	3	101		
	4	102		
	5	103		
	6	104		
	7	105		
16	1	106		
	2	107		
	3	108		
	4	109		
	5	110		
	6	111		
	7	112		
17	1	113		
	2	114		
	3	115		
	4	116		
	5	117		
	6	118		
	7	119		
18	1	120		
	2	121		
	3	122		
	4	123		
	5	124		
	6	125		
	7	126		
19	1	127		