



The Traveler

Exploratory Reverb

MANUAL

Introducing "The Traveler" - the ultimate reverb pedal for any musician. This compact and versatile pedal packs a punch with its three unique algorithms: Mod, Shimmer, and Vintage, giving you endless creative possibilities for your sound.

The three knobs, Mix, M, and Feedback, allow you to customize your tone with ease. Use the Mix knob to blend your wet signal, adjust the M knob to control a different unique feature on each algorithm, and the Feedback knob to control how long the reverb is. With "The Traveler", you can create anything from subtle reverb textures to full-blown sonic landscapes.

"The Traveler" also features MIDI capabilities, allowing you to control your presets, algorithms and features remotely. With the Hold function, you can instantly jump the feedback control to its max setting and then return to its previous place.

The six preset slots make it easy to switch between your favorite sounds, while the compact size makes it the perfect companion for gigging musicians. Whether you're playing in a small club or a large stadium, "The Traveler" will deliver the perfect tone every time.

"The Traveler" is the ideal guitar pedal for any musician looking for a compact, versatile, and high-quality effect. With its three unique algorithms, MIDI capabilities, Hold function, and six preset slots, you will explore new sonic landscapes with "The Traveler" - your ultimate musical companion

THANK YOU!

for purchasing a Traveler Exploratory reverb

DC Jack: takes an external DC 9v 120ma power draw.

Output Jack

Input Jack

MIDI Commands

PC Commands:

- PC0 : Bypass Toggle
- PC1 : Preset 1
- PC2 : Preset 2
- PC3 : Preset 3
- PC4 : Preset 4
- PC5 : Preset 5
- PC6 : Preset 6


CC Commands

- CC0: Bypass control
 - 0: Turn Pedal Off
 - 1: Turn Pedal On
 - 2: Toggle Bypass
- CC1 : 0-127 : Mix Control
- CC2 : 0-127 : M Control
- CC3 : 0-127 : Feedback Control
- CC4 : Algorithm Control
 - 0: Vintage
 - 1: Shimmer
 - 2: Mod
- CC5 : 1-16 : Sets MIDI channel

Pedal default is set to MIDI channel 1.

Factory Reset: Unplug the power to your pedal. While holding the "Bypass" switch plug in the power. You will see the "Bypass" led blink different colors. Release and Press the "Bypass" switch again to return to normal operation.

Presets: The Traveler has 6 built in presets. On powering up the pedal will automatically check if you have anything saved to preset 1. If you have nothing saved the pedal will boot up and load the current positions of the knobs. If you have saved something it will load preset 1 every time it boots up. You can access the other presets, 2-6, via MIDI.



If the pedal is off the "Bypass" led will flip on to confirm your selection before turning back off automatically.

Bypass/Hold:

- Press and release will turn the pedal on/off.
- Holding will turn the feedback to max, when released it will return to its previous place.
- Double press and hold to enter "Save Mode". Press the switch again to save to preset 1 or send a PC message to save to that preset slot. For example enter "Save Mode" and send PC3 to save to preset 3

The pedal will remember the last state it was in when power cycled. If you power it off with the pedal turned on it will power up turned on.

For additional information go to

MATTHEWSEFFECTS.COM



@matthewseffects