

MIDI Command			
PC Commands	Message 1	Function	
	PC #0	Bypass Toggle	
	PC #1	Preset 1	
	PC #2	Preset 2	
	PC #3	Preset 3	
	PC #4	Preset 4	
	PC #5	Preset 5	
	PC #6	Preset 6	
CC Commands	Message 1	Message 2	Function
	CC #0		
			0 Turn Pedal Off
			1 Turn Pedal On
			2 Toggle Bypass
	CC #1		
		0-127	"Mix" Control
	CC #2		
		0-127	"M" Control
	CC #3		
		0-127	"Feedback" Control
	CC #4		Algorithm control
			0 Vintage
			1 Shimmer
			2 Mod
	CC #5		
		1-16	Set MIDI Channel