


GAMING MONITOR

GOLSLAYERI



GAMEON

MADE BY GAMERS

USER MANUAL


Assembling Instruction


ATTENTION: Do not tighten the screws until all of them are in right positions






















1. Please check the manual carefully and make sure you have receive all the parts.

2. If there is any missing, please let us know the letter of the parts you need.



3. If there is any damage, please send clear photos to us, we will check and offer you best solution soon.







 <p>A *2</p>	 <p>B *2</p>	 <p>C *1</p>	 <p>D *1</p>	 <p>E *1</p>	
 <p>F *1</p>	 <p>G *2</p>	 <p>H *1</p>	 <p>J *1</p>	 <p>K *1</p>	
 <p>L *1</p>	 <p>M *1</p>	 <p>N *2</p>	 <p>P *1</p>	 <p>① * 8 M6*40</p>	
 <p>② * 2 M6*30</p>	 <p>③ *11 M6*25</p>	 <p>④ *15 M6*10</p>	 <p>⑤ *4 M6*40</p>	 <p>⑥ *6</p>	


1





2





3





4





5





6






7






8





9





9





5





6





7





8




1





2

























3



4




					
2* ^ا	2* ^ب	1* ^ج	1* ^د	1* ^{هـ}	
					
F*1	2* ^ز	1* ^ح	1* ^ي	1* ^ك	
					
L*1	1* ^م	2* ^ن	1* ^ف	① * 8 M6*40	
					
② * 2 M6*30	③ *11 M6*25	④ *15 M6*10	⑤ *4 M6*40	⑥ *6	



تجميع التعليمات

تنبيه: لا تشد المسامير اللولبية حتى تصح جميعها في المواضع الصحيحة

1. يرجى التحقق من الدليل بعناية والتأكد من استلام جميع الأجزاء.
2. إذا كان هناك أي مفقود ، فيرجى إخبارنا بحرف الأجزاء التي تحتاجها.
3. إذا كان هناك أي ضرر ، يرجى إرسال صور واضحة لنا ، وسوف نتحقق ونقدم لك أفضل الحلول قريباً.



شاشة ألعاب

GOLSLAYERI



دليل المستخدم