

US UK

Dear user


Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

OS support

Windows XP/Vista/Win7/Win8/Win10

How to connect the keyboard with a computer



Wired Connection

1. Slide the ON/OFF switch on left side of the keyboard to OFF.
2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer.

1

2

3. The computer will recognize and configure the keyboard automatically.
4. Once the keyboard is powered up, charging begins, LED of battery will turn to green when charge complete.

2.4G Wireless Connection

1. Slide the ON/OFF switch on left side of keyboard to ON.
2. Slide the 2.4G/B1/B2 switch to 2.4G.
3. Press [FN2]+[ESC] for about 3 seconds, the LED marked with M flashes quickly in Blue, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically.

Bluetooth Connection

1. Slide the ON/OFF switch on left side of keyboard to ON.
 2. Slide the 2.4G/B1/B2 switch to B1 or B2.
 3. Press [FN2]+[ESC], the LED marked with M flashes in Red(B1) or Green(B2).
- Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0Keyboard or BT5.0 KB" device. Select one of them to get connected with it automatically.

Function Introduction

1. With standard USB and 2.4G/BT connections, the keyboard can be used on computer without any software or driver installation.
2. There are 18 backlight effects, switch by press FN2+9.
3. Commands of key combinations with [FN2] key
 - [FN2]+[9]: Change backlight mode. There are 18 backlight effects.
 - [FN2]+[8]: Change backlight color.
 - [FN2] + [-]/[+]: Brightness +/-, total 6 levels.
 - [FN2]+[0]: Turn ON/OFF the backlight.
 - [FN2]+[backspace]: Lighting record function.
 - Press [FN2]+[backspace] to get ready recording mode,

3

- Press [FN2]+[backspace] again to start the recoding, then keep press the desired key for a favor LED color, press [FN2]+[backspace] again to save setting.
4. Commands of key combinations with [FN1] key
 - [FN1] + [Win]: Disable or enable the [Win] key.
 - [FN1] + [CAPSLK]: Set the keyboard to default setting.
 - [FN1]+[ESC]= ~
 - [FN1]+[!~0]= F1~F10
 - [FN1]+[-_]= F11
 - [FN1]+[+]= F12
 - [FN1]+[A]= ←
 - [FN1]+[S]= ↓
 - [FN1]+[D]= →
 - [FN1]+[W]= ↑
 - [FN1]+[P]=PRTSC
 - [FN1]+[[]]=HOME
 - [FN1]+[]]=END
 - [FN1]+[;]=PGUP
 - [FN1]+[>]=INSERT
 - [FN1]+[/]=DELETE

How to recharge the keyboard

The LED indicator of battery will turn to red when keyboard is out of battery. Find the USB A to USB type C cable in the packaging, plug the keyboard and connect it with computer for charging.

4

FAQ

1. If the keyboard doesn't respond, please check if the keyboard's USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please remove keyboard's USB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.

5

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



6

ES

Estimado usuario


Gracias por elegir REDRAGON Lite. Para proteger sus derechos y obtener un mejor servicio al cliente, le pedimos que preste atención a las reglas de la garantía.

1. Dentro del periodo de garantía, la reparación está garantizada por fallas debido a problemas en el circuito eléctrico. Los daños causados por el hombre, como desmontaje, impactos fuertes, inmersión en agua, conexión a una corriente o a un voltaje incorrecto y los daños causados por desastres naturales como incendios, inundaciones o terremotos no están incluidos.
2. Las partes consumibles (tal como un bastón) y el reemplazo de repuestos no está incluido en nuestra garantía.

Sistemas Operativos admitidos

WinXP / Vista / Win7 / Win8 / Win10

Cómo conectar el teclado a una computadora



Conexión por cable

1. Mueva el interruptor de Encendido / Apagado en la parte inferior del teclado a Apagado.
2. Retire el cable USB A a USB tipo C del paquete y conecte el teclado a la computadora.

2

3. La computadora reconocerá y configurará el teclado automáticamente.
4. Cuando se encienda el teclado, iniciará la carga. El LED de la batería se volverá verde cuando se complete la carga.

Conexión inalámbrica de 2.4G

1. Mueva el interruptor de Encendido / Apagado en la parte inferior del teclado a Apagado.
2. Mueva el interruptor de 2.4G / B1 / B2 a 2.4G.
3. Presione [FN2] + [ESC] durante casi 3 segundos, el LED marcado con M destellará rápidamente en azul, conecte el receptor USB a un puerto USB disponible en la computadora en menos de 20 segundos. La computadora reconocerá y configurará el teclado automáticamente.

Conexión por Bluetooth

1. Mueva el interruptor de Encendido / Apagado en la parte inferior del teclado a Encendido.
2. Mueva el interruptor de 2.4G / B1 / B2 a B1 o B2.
3. Presione [FN2] + [ESC], el LED marcado con M destellará en rojo (B1) o verde (B2). Active Bluetooth y busque dispositivos disponibles en la computadora o el teléfono inteligente. Encontrará "BT3.0Keyboard o BT5.0 KB". Elija lo y se conectará automáticamente.

Introducción a las funciones

1. Con conexiones estándares USB y 2.4G / BT, el teclado se puede usar en computadoras sin ningún software o instalación de controladores.
2. Hay 18 efectos de retroiluminación, puede cambiarlos al presionar las teclas FN2 + 9.
3. Comandos de combinaciones de teclas con la tecla [FN2].
 - [FN2] + [9]: cambia el modo de la retroiluminación.
 - [FN2] + [8]: cambia el color de la retroiluminación.
 - [FN2] + [-] / [+]: reduce / aumenta el brillo hay *6 niveles en total.

3

- [FN2] + [0]: enciende / apaga la retroiluminación.
- [FN2] + [Retroceso]: función de grabación de la iluminación.
- Presione [FN2] + [Retroceso] para preparar el modo de grabación, presione [FN2] + [Retroceso] nuevamente para iniciar la grabación, luego mantenga presionada la tecla deseada para elegir un color de LED, presione [FN2] + [Retroceso] nuevamente para guardar configuración.
- Comandos de combinaciones de teclas con la tecla [FN1]
 - [FN1] + [Win]: deshabilita o habilita la tecla [Win].
 - [FN1] + [BlokMayús]: establece el teclado a la configuración predeterminada.
 - [FN1] + [ESC] = ~
 - [FN1] + [!~0] = F1 ~ F10
 - [FN1] + [-_] = F11
 - [FN1] + [+]= F12
 - [FN1] + [A] = ←
 - [FN1] + [S] = ↓
 - [FN1] + [D] = →
 - [FN1] + [W] = ↑
 - [FN1] + [P] = ImprPant
 - [FN1] + [[]] = Inicio
 - [FN1] + []] = Fin
 - [FN1] + [;] = RePág
 - [FN1] + [>] = Insertar
 - [FN1] + [/?] = Suprimir

Cómo cargar el teclado

El indicador LED de la batería se volverá rojo cuando el teclado no tenga suficiente carga. Busque el cable USB A a USB tipo C en el paquete, enchufe el teclado y conéctelo a la computadora para cargarlo.

4

Preguntas frecuentes

1. Si el teclado no responde, compruebe si el cable USB del teclado está insertado correctamente en el puerto USB correspondiente en la computadora, o pruebe con otro puerto USB en la misma.
2. Si derrama líquido sobre el teclado, desconecte el cable USB del teclado de la computadora inmediatamente. Limpie el exceso de líquido y coloque el teclado en un lugar seco y ventilado. Asegúrese de que el teclado se seque naturalmente antes de su próximo uso.

5



REDRAGON
DRACONIC PRO
 WIRED /2.4G /BT MECHANICAL GAMING KEYBOARD



Please scan here to download user manual

Mechanical Gaming Keyboard
Operating Instructions

型号	K530RGB-PRO/8639	备注：尺寸：100x100mm (折页)
名称	说明书	材质：80g书写纸
日期	2022-1-10	印刷：单黑色双面印刷
页码	1 OF 1	文件编号
绘图	雷国建	审核
		核准
		版本
		A.0