

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

1

OS support

Windows XP/Vista/Win7/Win8/Win10

How to connect the keyboard with a computer

Wired Connection

1. Take out the USB Type C to USB A cable in the package and connect the keyboard with your computer.
2. The computer will recognize and configure the keyboard automatically.
3. The keyboard will be ready for use when the configuration is finished.
4. Once the keyboard is powered up, charging begins. It may take about 5 hours for the keyboard to be fully recharged.

Wireless Connection

1. Slide the ON/OFF switch on the left side of the keyboard to ON.
2. Take out the nano USB receiver and plug it into an available USB port on your computer. The computer will recognize and configure the keyboard automatically.
3. The keyboard will be ready for use when the configuration is finished.
4. The keyboard can work under normal use approx 350 hours without LED backlight, and can work under normal use approx 20 hours with fully LED backlight.
5. In some cases, you may need to pair the keyboard. Turn on the keyboard and press [FN]+[K], plug the USB receiver into any available USB port on your computer within 20 seconds. The keyboard will be paired automatically. Make sure the keyboard has enough power before doing so.
6. The backlight will flash when the battery is low. Please recharge the keyboard in time or it will turn off automatically soon.

 **Warning: Charging Input: 5V ---1A**

2

Function Introduction

1. Standard USB A plug for connection with computer. Plug and play without drivers or software installation.
2. Multi-level backlight brightness: Press and hold the [FN] +[↑]/[↓] to increase or decrease backlight brightness of the keyboard.
3. There are 18 backlighting effects. Press the combination keys repeatedly:
[FN] + [Insert]: 1. The trial of light; 2. Breathing; 3. Normally on
[FN] + [Del]: 1. Go with the stream; 2. Clouds fly; 3. Winding Paths
[FN] + [Page Up]: 1. Both ways; 2. Surmount; 3. Fast and the furious
[FN] + [Home]: 1. Ripple Graff; 2. Pass without Trace; 3. Coastal
[FN] + [End]: 1. Flowers blooming; 2. Snow winter jasmine; 3. Swift action
[FN] + [Page Down]: 1. Hurricane; 2. Accumulate; 3. Digital Times
4. To disable or enable the [WIN] and right [CTRL] key: Press [FN]+ [WIN] key to disable or enable the [WIN] and right [CTRL] key so as to avoid quitting the game by accident.
5. Alterable backlight changing direction: Press [FN] + [←] to alter backlight changing direction.
6. Changeable backlight colors: Press [FN]+[→] to change backlight colors (8 color option).
7. Adjustable lighting speed: Press FN+ [,] to decrease lighting effect speed and Press FN+[,] to increase lighting effect speed.
8. Customized backlighting mode: Press FN+ [TAB] to show User's backlighting definition mode, Press FN + [TAB] again, key [TAB] will flashes to enter start recording status, Press the desired key for colour setting, Press FN + [→] to selet colour, there are 8 colour setting, Press FN+ [TAB] again to save the setting.
For example, set [T] key as BLUE colour: Press FN+ [TAB] →Press FN+ [TAB] → press the key [T] → press FN + [→] to switch [T] key as BLUE colour →press FN+[TAB] again to save the setting.
9. Reset the keyboard to factory setting: [FN]+[CAPSLK]
10. Wireless keyboard pairing: [FN]+K

3

Function Combination keys

[FN]+[ESC]	`	[FN]+[I]	Print Screen
[FN]+[1]	F1	[FN]+[O]	SCLK
[FN]+[2]	F2	[FN]+[P]	PAUSE
[FN]+[3]	F3	[FN]+[Z]	Volume Down
[FN]+[4]	F4	[FN]+[X]	Volume Up
[FN]+[5]	F5	[FN]+[V]	Stop
[FN]+[6]	F6	[FN]+[B]	Previous Track
[FN]+[7]	F7	[FN]+[N]	Play/Pause
[FN]+[8]	F8	[FN]+[M]	Next Track
[FN]+[9]	F9	[FN]+[CTRL](right)	APP
[FN]+[0]	F10	[FN]+[C]	Mute
[FN]+[-]	F11	[FN]+[Shift]+[ESC]	~
[FN]=[F12		

4

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug USB cable of the keyboard from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before next use.



5

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

6




REDRAGON
DEIMOS
Dual Mode RGB Mechanical Keyboard



Please scan here to download user manual

Dual Mode RGB Mechanical Keyboard
Operating Instructions

型号	红龙K599-KBS/8475	备注：尺寸：100x100mm (折页)		Easternimes Tech 
名称	说明书	材质：80g书写纸		
日期	2021-12-30	印刷：单黑色双面印刷		
页码	1 OF 1	文件编号		
绘图	雷国建	审核	核准	版本 A.0