

WELCOME TO FIFINE

Thank you for showing your confidence in us by purchasing the FIFINE N5. This 4-channel mixer is perfect for anyone wanting to mix 4 line level signals quickly and without complications. Despite its compact size, this mixer produces highest signal quality even at highest levels, in highest signal integrity.

WHAT'S IN THE BOX?

- 1. N5 Line Mixer
- 2. Power Adapter






N5 connectors and control elements

① Connect the power supply unit to your N5 using the 12V connector. Connecting the power supply unit to the mains automatically switches the N5 on. To disconnect the unit from the mains, pull out the main cord plug. Note: When installing the product, ensure that the plug is easily accessible. If mounting in a rack, ensure that the mains can be easily disconnected by a plug or by an all-pole disconnect switch on or near the rack.


- ② Up to four line signal sources can be connected to these 1/4" TRS connectors. (INPUT) Note: In case the volume level of one of the signal sources is set too high, the input of the corresponding channel may produce distortion!
- 3 The OUTPUT carries the MIX signal and is on a 1/4" TRS connector.
- 4 This ON LED is illuminated as soon as the unit is connected to the power.
- ⑤ Using the LEVEL controls you can set the output level of each channel. Note: High volume levels can damage your hearing or your headphones. Please turn down all volume controls to zero (all the way to the left) before you power up

the amp. Always make sure you use appropriate volume levels.


Stereo version: You must use the 1/4" TRS stereo audio cable male to male connectors for input and meanwhile use the 1/4" TRS stereo audio cable male to male connectors for output connection (1/4" Male to Male Stereo Audio Cable (TRS Cable) is the key point)



Mono version: Mixes down 4 mono signal inputs into 1 mono signal output(1/4" TS male to male connectors for input and output connection).



The following figure shows an example of how to use the mixer N5



SPECIFICATIONS

LINE INPUTS Type 1/4" TRS connector Impedance: 47k Max.input level: +16dBu

4

OUTPUT

Type 1/4" TRS connector Impedance: approx 47 Max.output level: +16dBu

POWER SUPPLY

External power supply: 12V/1A Max. output level: approx 50mW

DIMENSIONS/WEIGHT

Dimension(HxDxW): approx 1.57"x2.36"x 4.72" (approx 40mm x 60mm x 120mm) Weight: approx.0.43 lbs(217g)

INTRODUCTION

- Ultra low-noise 4-channel line mixer.
- Highest sonic quality even at maximum output level.
- 4 Input Level control for each channel with individual volume control .
- 2-Year online registration Warranty Program.

IMPORTANT SAFETY INSTRUCTIONS

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.

5

- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 10) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 11) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
- 12) Please add a ground loop noise isolator on the line from your computer and into the mixer if there is humming bzzing noise when mixing the computer and other device audio.

6

CONTACTUS

Get Social:

Facebook page:http://bit.ly/FifinePage

Contact Info: E-mail:web@fifine.cc

More product inquiries can be found on the Company Website:https://fifinemicrophone.com/

WARRANTY

Fifine microphone warrants its hardware product defects in materials and workmanship for a period of one year from the date of original retail purchase, provided the purchase was made from authorized Fifine microphone dealer. This warranty is void if the equipment is altered, misused, mishandled, suffers excessive wear or is serviced by any parties not authorized by Fifine Microphone. For warranty service, contact your local distributor or web@fifine.cc.



USER'S GUIDE



B2B Version: 22-07