

IN THE BOX

- 1 - QuickDrift™ Leader Storage System
- 1 - Adjustable Shoulder Strap
- 24 - Drift Spools
- 4 - Floating Quick Connectors
 - 2 – Standard
 - 2 – Micro
- 4 - Sinking Quick Connectors
 - 2 – Standard
 - 2 - Micro



Floating



Sinking



Quick
Connect



Drift Spool

Connect to Main Line

Shortened Tapered Leader



1. Attach tapered leader to main line and shorten to 3' - 4'
2. Attach Quick Connect to tapered leader
3. Select pre-tied rig and attach to Quick Connect
4. Fish On!

Direct to line Setup




1. Attach Quick Connect to main fly line
2. Select pre-tied rig and attach to Quick Connect
3. Your ready to Cast!

How to – Quick Connect


To Connect:

1. Slide the loop of your pre-tied rig over the tip of the Quick Connect
2. Rotate upward until the loop passes the catch tab
3. Reverse rotation direction so both legs of the loop hook under the tab
4. Snap snug – ready to fish



To Disconnect:


1. Lay the loop in the lower slot
2. Pull up to release the snap
3. Rotate upward while pulling away until the loop releases
4. Slide off the Quick Connect



USING DRIFT SPOOLS

To Wind a Rig

1. Hook the loop to a catch tab opposite the tension slot, securing with your thumb.
2. Slide the line into the tension slot
3. Release your thumb and wind away from slot



Secure Fly

1. Hold the spool steady and orient the hook toward the spool.
2. Hook the fly around a catch tab
3. Stow the spool back into the QuickDrift™



Unwind

1. Hold the spool between your thumb and middle finger.
 2. Unhook the fly and gently pull to unwind
- ⚠ **Caution:** Hold securely to avoid dropping if line catches.



CARE + MAINTENANCE

Keep it Clean

- Rinse spools and case to remove sand or grit.
- Let everything dry before storage to prevent mold or odor.
- Avoid excessive heat

Inspect Regularly


- Check connectors and foam tension tabs for wear.
- Replace any damaged parts.

Pro Tips

- If the fly doesn't align to a catch tab on the spool for easy hook up, "Short Circuit" the outside of the spool to adjust hook point.



- Use color-coded spools for various rig types
- Use Wool with flotant to increase buoyancy and visibility of the floating Quick Connect



QuickDrift™



RIG FASTER. FISH LONGER

**PRE-RIG TIPPET SETUPS
AND SWAP THEM IN
SECONDS**



© 2025 Flytime Fishing, LLC · Patent Pending · Designed in Idaho, USA · support@flytimefishing.com

www.FlytimeFishing.com