


# Utility Vapor Tight Fixture

## User Manual

### 01 / WARNING

- Review the diagrams before beginning, and make sure fixture is grounded properly.
- For lighting controls, using functioning correctly.
- Turn power off and wait for fixture cooling to operate.
- Maintenance must be done by professionals.

### 02 / COMPONENT



Bracket




Screws




Expanding nuts

### 03 / INSTALLATION


1. Drill two desired holes on the ceiling as shown in the picture below.




2. Tap the expanding nut into the holes.



3. Pass screw through the bracket, and then insert into expanding nuts. Make sure that the bracket is fixed well.



4. Lift up the fixture and fasten to the bracket. Connect the L, N, GND wires to the corresponding wires of the AC cord from the ceiling. The installation is finished.



### 04 / WARRANTY

LeonLite warrants that this product is free from defects in materials and workmanship for a period of 5 years from the day of purchase. This warranty does not apply if the product has been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling.