

# 3-Head Ceiling Spotlight

## User Manual

---

### 01 / WARNING

**IMPORTANT: NEVER attempt any work before turning off the power.**

1. Carefully read ALL instructions before installing.
2. This fixture must be installed by a qualified electrician following the National Electrical Code and local regulations.
3. TURN OFF THE POWER at the circuit breaker or remove the appropriate fuse for the room or fixture you are working on.
4. Place the wall switch in the "OFF" position.
5. Dry location rated.

### 02 / PACKAGE CONTENT

- 3-head ceiling spotlight × 1
- Mounting screws × 2

### 03 / INSTALLATION

1. Remove the screw caps from the lamp base, then remove the mounting bracket.
2. Pull the supply out from the junction box and pass them through the mounting bracket's hole.
3. Connect the supply wires to the fixture wires through the knockout. Connect the black wire to the live wire, the white wire to the neutral wire, and the bare copper wire to the ground wire. Using electrical tape, wrap up all wire connections.
4. Carefully tuck the wiring back into the junction box.
5. Use the mounting screws to attach the mounting bracket to the junction box.
6. Lift the lamp base and adjust it until the screws on the mounting bracket protrude enough from the lamp base. Using the screw caps, attach the lamp base to the mounting bracket.
7. Once assembly is complete, turn the power back on to check if the fixture is working properly.

### 04 / SPECIFICATIONS

3-Head Ceiling Spotlight	
Power	36W
Voltage	120V
Working temperature	-4°F-104°F
Luminous flux	2800lm
CRI	90
Color temperature	3000K Warm White
Material	Aluminum
Beam angle	34°
Equivalent	70W*3

### 05 / WARRANTY

LEONLITE warrants that this product is free from defects in materials and workmanship for a period of 5 years from the day of purchase. If the product has been misused, damaged by accident or in any other way of improper use, this warranty becomes void.

**LeonLite**