

# LED Up Down Wall Lamp

## User Manual

### 01 / WARNING


1. PLEASE unplug the power when installing or overhauling the lamp to avoid dangerous accidents.
2. The installation and maintenance of this lamp must be performed by a professional.

### 02 / CAUTION


1. PLEASE read the specifications of the product carefully and make sure the environment of the application meets what the product needs.
2. PLEASE DO NOT cover anything on the lamp to avoid high temperatures.
3. DO NOT install this product in sources of water.
4. PLEASE keep this product away from sources of fires, environments of high temperatures or corrosive gas as they may shorten its service life.

### 03 / INSTALLATION


1. Open the package, take the lamp out and make sure there is no damage.




2. Install the mounting plate to the junction box (not included) with mounting screws.



3. Take out the wire connectors in the attached bags, connect the input wire from the fixture to the internal wire from the junction box (not included), and tighten wires with wire caps.



4. Fix the lamp to the mounting plate with screws and tighten the screws to ensure the lamp is firmly fixed.



### 04 / WARRANTY

LeonLite warrants that this product is free from defects in materials and workmanship for a period of 5 years from the day of purchase. This warranty does not apply if the product has been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling.

**LeonLite**