

# 24W Up Down Wall Sconce

## User Manual

### 01 / WARNING


1. PLEASE make sure that the power to the outlet box is turned off before installing.
2. Carefully unpack the product and lay out all parts in a clear area. Be careful NOT to lose any small parts necessary for the installation.

### 02 / PACKAGE CONTENT


- 24W up down wall sconce × 1
- Wire nuts × 3
- Screws × 2
- Hex key × 1

### 03 / INSTALLATION

1. TURN OFF THE POWER. Remove the screws from the side of the fixture. Then remove the mounting plate from the fixture. Using the screws in the accessory bag, attach the mounting plate to the J-box (not included).
2. Connect the wires using the wire nuts. Connect the black wire to the line wire, the white wire to the neutral wire, and the bare copper wire to the ground wire.



3. Reattach the fixture to the mounting plate using the screws.



4. The installation is now complete. Fill the gap between the fixture and wall using silicone sealant. Turn the power back on.



### 04 / SPECIFICATIONS

24W Up Down Wall Sconce	
Power	24W
Voltage	120V
Waterproof rating	Wet location
Material	Aluminum
CRI	>90

### 05 / WARRANTY

LEONLITE warrants that this product is free from defects in materials and workmanship for a period of 3 years from the day of purchase. If the product has been misused, damaged by accident or in any other way of improper use, this warranty becomes void.