18W Outdoor Cuboid Wall Light

User Manual

O1/WARNING

READ & FOLLOW ALL SAFETY INFORMATION.

- 1. CAUTION Turn off the power at the circuit breaker before installing and servicing this fixture to prevent possible injury from electric shock.
- 2. All electrical connections must follow local and Nation Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, PLEASE obtain the services of a qualified electrician.

02 / PACKAGE CONTENT


18W outdoor cuboid wall light × 1

Screws × 2

Wire nuts × 3

03 / INSTALLATION

Take the fixture and the accessories out of the box and make sure that there are no missing parts by checking the user manual.



- 1. TURN OFF THE POWER before installing. Unscrew the two screws on the mounting canopy's side, then remove the mounting bracket.
- 2. Use screws to attach the mounting bracket to the junction box (not included).
- 3. Using wire nuts connect the fixture and supply wires. Connect the black wire to the live wire, the white wire to the neutral wire, and the bare copper wire to the ground wire. Using electrical tape (not included), wrap up the wire connections, then carefully tuck them all back into the junction box.
- 4. Using screws, attach the fixture to the mounting bracket, then turn the power back on. The installation is now complete.
- 5. After installing the fixture, caulk the upper 2/3 of the canopy. Leave the bottom 1/3 un-caulked to allow water drainage. We recommend a non-drying exterior caulking material. A good example is a clear silicone rubber sealant for exterior use.

04 / CARE AND MAINTENANCE

- 1. Use a dry and clean cloth to wipe the surface of the fixture.
- 2. THERE ARE NO BULBS TO REPLACE IN THIS LED FIXTURE.

05 / SPECIFICATIONS

18W Outdoor Cuboid Wall Light	
Power	18W
Voltage	120V
Working temperature	-4°F-104°F
Luminous flux	1100lm
CRI	>80
Color temperature	3000K Warm White
Material	Aluminum
Beam angle	120°

06/WARRANTY

LEONLITE warrants that this product is free from defects in materials and workmanship for a period of 5 years from the day of purchase. If the product has been misused, damaged by accident or in any other way of improper use, this warranty becomes void.

