

# LED Temporary Work Light

## User Manual

- Thank you for purchasing our LED temporary light. Please read the below articles carefully to see how to use this product safely.
- Warning contents and attention contents are related to the safe use of the product, please be sure to follow them.

### 01 / ATTENTION


- Please keep the temporary light away from any corrosive substance when you clean it, please use dry cloth.
- Due to the temporary light are installed on the high place, please ensure personal safety when you install them.

### 02 / WARNING


- Make sure the distances between live part and metal part of the LED temporary light can satisfy reinforce or double insulation.
- Before installation and maintenance of the temporary light, please disconnect the power to prevent electric shock.
- The temporary light must be installed in an appropriate environment to work. In harsh environments may shorten the life even damage the temporary light.
- If need to remove the lamp, please take off the lamp after it is cool sufficiently.

### 03 / INSTALLATION


Step1: Use the hook to install the lamp, and tightening O hook.



Step 2: Ensure the fixed wall strong enough can bear 30KG.



Step 3: Connect each temporary work light. Max. 8pcs 100W in series. Turn on the power(AC 100-277V) and test.



### 04 / WARRANTY

LEONLITE warrants that this product is free from defects in materials and workmanship for a period of 5 years from the day of purchase. This warranty does not apply if the product has been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling.