



ASSEMBLY INSTRUCTIONS

www.eurekaergonomic.com

MODEL # **ERK-DC19**

DINING CHAIR

DC03餐椅




If you need to return the goods, please keep all the packaging materials and return it in the original packaging.
Si vous devez retourner la marchandise, veuillez conserver tous les matériaux d'emballage et le retourner dans l'emballage d'origine.
Si necesita devolver los productos, conserve todos los materiales de embalaje y devuélvalos en el embalaje original.
如需退货请保留好所有包装材料，并按原包装包好退回。

PARTS / PIÈCES / PARTES / 部件清单



HARDWARE / MATÉRIEL / HARDWARE / 配件清单






ASSEMBLY INSTRUCTIONS

INSTRUCTIONS DE MONTAGE

INSTRUCCIONES DE MONTAJE

安装说明



Screws should be placed vertically into the holes.
les vis doivent être placées verticalement dans les trous.
Los tornillos deben colocarse verticalmente en los orificios.
螺丝要垂直放入孔位。